



















ASSEMBLY INSTRUCTION


E453BQ QUEEN BED

A Headboard Left Leg 1pc 	B Headboard 1pc 	C Headboard Right Leg 1pc 	D Headboard K/D Leg 2pcs 
E Left Side Panel - Front 1pc 	F Left Side Panel - Rear 1pc 	G Right Side Panel - Front 1pc 	H Right Side Panel - Rear 1pc 
I Footboard 1pc 	J Footboard K/D Leg 2pcs 	K Slat 5pcs 	L Support Leg 10pcs 
M Bolt Ø1/4"x1-1/2" 10pcs 	N Bolt Ø1/4"x5/8" 32pcs 	O Lock Washer Ø10.5xØ7x1.5mm 32pcs 	P Flat Washer Ø16xØ7x1.5mm 32pcs 
Q Allen Key M4 1pc 			




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this products. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


- 1** Attach Headboard (B) to the Headboard Left Leg (A) and Headboard Right Leg (C) using Bolt (N), Lock Washer (O), Flat Washer (P) by Allen Key (Q). Attach Headboard K/D Leg (D) to Headboard Right Leg (C) and Headboard Left Leg (A) as below picture shown.




- 2** Attach Right Side Panel - Front (G) to Right Side Panel - Rear (H) using Bolt (N), Lock Washer (O), Flat Washer (P) by Allen Key (Q).




- 3** Attach Left Side Panel - Front (E) to Left Side Panel - Rear (F) using Bolt (N), Lock Washer (O), Flat Washer (P) by Allen Key (Q).




- 4** Attach Footboard K/D Leg (J) to Footboard (I) using Bolt (N), Lock Washer (O), Flat Washer (P) by Allen Key (Q). Connect Side Panel (H&F) and Footboard K/D Leg (J) using Bolt (N), Lock Washer (O), Flat Washer (P) by Allen Key (Q). Then attach Headboard K/D Leg (D) to Side Panel (G&E) using Bolt (N), Lock Washer (O), Flat Washer (P) by Allen Key (Q).



-
- 5** Attach Support Leg (L) to Slat (K) using Bolt (M) by Allen Key (Q).



- 6** Attach Slat (K) to Side Panel (E), (G), (F), (H) using Bolt (N), Lock Washer (O), Flat Washer (P) by Allen Key (Q).












Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.

ASSEMBLY INSTRUCTION


E453-13 BENCH WITH CUSHION

A Seat	B Leg	C Stretcher	D Short Leg
			
1pc	4pcs	1pc	4pcs
E Bolt Ø1/4"x5/8"	F Lock Washer Ø10.5xØ7x1.5mm	G Flat Washer Ø16xØ7x1.5mm	H Allen Key M4
			
8pcs	8pcs	8pcs	1pc




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


-
- 1** Put Seat (A) on a smooth flat surface and attach the Leg (B) to Seat (A) using Bolt (E), Lock Washer (F), Flat Washer (G) by Allen Key (H).
-



-
- 2** Attach Stretcher (C) to Leg (B) as picture shown.
-



3 Attach Short Leg (D) to Leg (B) as picture shown.



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.