





ITEM NAME/NOM D' ITEM: SIEVE SWIVEL DINING CHAIR
ITEM #/NO.ITEM: 704213

PARTS LIST/LISTE DES PIÈCES


(1)	(2)	(3)
 x1	 x1	A.  x4 M6*15 B.  x4 Φ16*Φ6.2*1.0 C.  x1 M6

ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE

I



II



Please use the attached adjustable footglides to level the dining chair on an uneven surface.