
# **™** Dimplex®

#### Owner's Manual



**IMPORTANT SAFETY INFORMATION:** Always read this manual first before attempting to install or use this heater. For your safety, always comply with all warnings and safety instructions contained in this manual to prevent personal injury or property damage.

To view the full line of Dimplex products, please visit www.dimplex.com



#### Table of Contents

<b>(i)</b>	Welcome & Congratulations
A	IMPORTANT INSTRUCTIONS
*	Heater Installation6
•	Operation
	Maintenance14
	Technical Support
Ø	Warranty

Always use a qualified technician or service agency to repair this heater.

! NOTE: Procedures and techniques that are considered important enough to emphasize.

**A** CAUTION: Procedures and techniques which, if not carefully followed, will result in damage to the equipment.

**WARNING:** Procedures and techniques which, if not carefully followed, will expose the user to the risk of fire, serious injury, or death.


### (i) Welcome & Congratulations

Thank you and congratulations for choosing to purchase a Dimplex electric heater.

Please carefully read and save these instructions.

**A** CAUTION: Read all instructions and warnings carefully before starting installation. Failure to follow these instructions may result in a possible electric shock, fire hazard and will void the warranty.

Please record your model and serial numbers below for future reference: model and serial numbers can be found on the Model and Serial Number Label of your heater.



# STOP NO NEED TO RETURN TO THE STORE

Questions with operation or assembly? Require Parts Information? Product Under Manufacturer's Warranty?

Contact us at: www.dimplex.com/customer\_support For Troubleshooting and Technical Support

OR Toll-Free 1-888-DIMPLEX (1-888-346-7539) Monday to Friday 8:00 a.m. to 4:30 p.m. EST Please have your model number and product serial number ready. (See above)

### **A** IMPORTANT INSTRUCTIONS

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- 1) Read all instructions before using the heater.
- 2 The heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. The surface around the heater outlet becomes hot during heater operation.
- **DANGER:** High temperatures may be generated under certain abnormal conditions. Do not partially or fully cover or obstruct the front of this heater.
- (3) Extreme caution is necessary when any heater is used by or near children or invalids and whenever the unit is left operating and unattended.
- 4 Always disconnect the heater when not in use.
- ⑤ Do not operate any heater after it malfunctions. Disconnect power at the service panel and have the heater inspected by a reputable electrician before reusing.

- 6 Do not operate any unit with a damaged cord or if the heater has malfunctioned, or if the heater has been dropped or damaged in any manner, contact Technical Service at 1-888-346-7539.
- (7) Do not use outdoors.
- 8 Never locate heater over a bathtub or other water container.
- To disconnect the unit, turn the controls OFF, disconnect power at the service panel.
- 10 Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage to the heater.
- 1 To prevent a possible fire, do not block air intake or exhaust in any manner.
- 12 All electrical heaters have hot and arcing or sparking parts inside. Do not use in areas where gasoline, paint, or flammable liquids are used or stored.
- 3 Do not modify the heater. Use it only as described in this manual. Any other use

4

### **A** IMPORTANT INSTRUCTIONS

not recommended by the manufacturer may cause fire, electric shock or injury to persons.

- (4) Always use a certified electrician should new circuits or outlets be required.
- (5) Always use properly grounded, fused and polarized outlets.
- (b) Disconnect all power supply before performing any cleaning, maintenance or relocation of the unit.
- (17) When transporting or storing the unit, keep in a dry place, free from excessive vibration and store so as to avoid damage.

! NOTE: Changes or modifications not expressly approved by the party responsible for compliance could void user's authority to operate the equipment.

#### For Bathroom Use

If this unit is installed in a bathroom it must be protected by a GFI receptacle or circuit. If receptacle is used it must be readily accessible.

To prevent electrical shock this unit is an electrical appliance that is not watertight and must be installed as to prevent water from entering unit. This must be installed away from showers, tubs, etc. Never locate heater where it may fall into a bathtub or other water container.



#### CAUTION

RISK OF ELECTRIC SHOCK DO NOT OPEN NO USER-SERVICABLE PARTS INSIDE



### SAVE THESE INSTRUCTIONS

WARNING: ANY
INSTALLATION AND
SERVICE WORK SHOULD BE
PERFORMED BY QUALIFIED
AND AUTHORIZED PERSONNEL.
ALL INSTALLATIONS MUST
COMPLY WITH ALL LOCAL
CODES AND BY-LAWS,
INSPECTED AND APPROVED
FOR OPERATION BY LOCAL
GOVERNING AUTHORITY PRIOR
TO USE.

**WARNING:** Construction and electrical outlet wiring must comply with local building codes and other applicable regulations to reduce the risk of fire, electric shock and injury to persons.

! NOTE: A 15 Amp, 120 Volt circuit is required. A dedicated circuit is preferred but not essential in all cases. A dedicated circuit will be required if, after installation, the circuit breaker trips or fuse blows on a regular basis when the heater is operating. Additional appliances on the same circuit may exceed the current rating of the circuit breaker.

#### **Hardwire Installation**

The heater is supplied in an assembled state and is designed to be permanently installed. The unit comes ready for hardwire installation.

**WARNING:** Do not attempt to wire your own new outlets or circuits. To reduce the risk of fire, electric shock or injury to persons, always use a licensed electrician.

- ! NOTE: Please read all instructions before installing.
- For rough in framing, the opening should follow the recommended dimensions located in Figure 2.
- ! NOTE: Dimensions provided are minimum clearances and will vary depending on type of support framing and finishing options.
- ! NOTE: Framing should be constructed to support 10 lbs (4.5 kg).

**A WARNING:** To reduce the risk of fire, do not store or use gasoline or other flammable vapors or liquids in the vicinity of the heater.

2. Allow at least 2 ft. (61 cm) of service cable for connecting the power supply wire.

**A** CAUTION: Keep min 6" clearance to the adjacent walls and min 18" clearance to the floor.

! NOTE: Use minimum 14 AWG supply cable with two insulated copper conductors (white and black) and one bare ground wire.

**! NOTE:** The heater only exhausts from one direction. Note this direction, see figure 7.





Figure 2



#### **Installation Options**


The heater can be installed on its own or with an Opti-myst cassette.


The unit needs to be installed so that the heater outlet is horizontal to the ground. The *required opening dimensions* for the heater are: 12.8" (326 mm) x 8.1" (206 mm) x 3.5" (89 mm) deep.


! NOTE: The heater does not require any additional venting.

! NOTE: Install the heater so that the pilot light can be seen 5 ft (153 cm) from the floor and 10 ft (305 cm) from the unit. (Figure 3)

Example:		
Distance from floor	Distance from front wall	
54"	6"	
36"	2"	







♠ CAUTION: Use two conductor, non-metallic sheath cable with ground wire (3 wires total) for the incoming power supply. Use appropriate wire to meet local and national electrical codes for rated power.

- 1. On the back of the unit, remove the cable clamp by removing the screw at the top (Figure 4).
- Install a 3/8" (10 mm) or 1/2 in. (13 mm) cable connector, not included, suitable for mounting in a 7/8" (22 mm) hole, to the cable plate and feed the supply cable through the connector and secure.
- 3. Remove the 3 wires from within the unit.
- Connect the black wire (live) from the unit to the black wire from power supply.

- Connect the white wire (neutral) from the unit to the white wire from power supply.
- Connect the green wire (ground) from the unit to the bare wire from the power supply.
- Place all connectors inside the unit and secure the cable plate to unit. Ensure that the cable clamp grips only the jacket of service cable.
  - ! NOTE: There is an access panel at the back of the heater where the wiring can be accessed for electrical inspection without disturbing the strain relief connector of the service cable.


♠ CAUTION: When inserting the unit take care not to damage or pinch any of the power cables that are concealed in the ceiling.

- ★ WARNING: Ensure the power wiring is not installed so that it is pinched or against a sharp edge to reduce the risk of fire, electric shock or injury to persons.
- Place unit into the finished opening. Using the provided screws, fasten the unit to the joists through the flanges.

## Installation with Opti-myst Cassette

Follow the installation instructions provided with the Opti-myst Cassette. Use additional sheathed cable to bring the power supply from the heater connection to the Opti-myst cassette or the other way around. (Figure 6).


#### Figure 5



Center the heater above the Opti-myst cassette for optimum flame performance. (Figure 5). Keep minimum 18" distance between the heater and cassette top, if you choose to use logs with the cassette increase the distance by min 5". Keep min 6" clearance from the adjacent walls.

Place all connections inside the appropriate terminal boxes and secure the cable clamps to the units (cassette and heater) making sure that the cable clamps grips only the jacket of the service cables.

#### Figure 6




**A** CAUTION: Ensure the wire connectors are securely tightened, so no bare wires (live or neutral) are exposed.

Connect the 2 pin connector to the 2 pin connector from the Opti-myst cassette heater control wire harness.

♠ WARNING: Disconnect power before attempting any maintenance or cleaning to reduce the risk of fire, electric shock or damage to persons.

### Operation



**WARNING:** This electric heater must be properly installed before it is used.

The On/Off switch supplies power to the heater. When the switch is in the 'I' position, the unit is On, and will be indicated by the red light. When the switch is in the 'O' position, the unit is Off.

When connected into a Dimplex Optimyst Cassette the heater can by controlled by remote control.

Refer to the cassette user's guide.

## Resetting the Temperature Cutoff Switch

Should the heater overheat, an automatic switch will turn the heater off and it will not come back on without being reset. The temperature cutoff switch can be reset by unplugging the unit, waiting 5 minutes and plugging the unit back in.

♠ CAUTION: If you need to continuously reset the heater, unplug the unit and call Glen Dimplex Americas at 1-888-346-7539 for technical support. Please have your model and serial number ready when calling.

### Maintenance

▲ WARNING: Disconnect power before attempting any maintenance or cleaning to reduce the risk of fire, electric shock or damage to persons.

! NOTE: The heater should not be operated with an accumulation of dust or dirt on or in the unit, as this can cause a build up of heat and eventual damage. For this reason the heater must be inspected regularly, depending upon conditions and at least at yearly intervals.

#### **Heater Surface Cleaning**

Use a cloth dampened with warm water only to clean painted surfaces of the electric heater. Do not use abrasive cleaners.

Use a vacuum cleaner to clean out dust that may have accumulated in the vents.



#### Technical Support

Technical and troubleshooting support, as well as a list of replacement parts can be found on www.dimplex.com/customer support

14



#### 2 YEAR LIMITED WARRANTY

Products to which this limited warranty applies

This limited warranty applies to your newly purchased Dimplex heater. This limited warranty applies only to purchases made in any province of Canada except for Yukon Territory, Nunavut, or Northwest Territories or in any of the 50 States of the USA (and the District of Columbia) except for Hawaii and Alaska. This limited warranty applies to the original purchaser of the Product only and is not transferable.

Products excluded from this limited warranty

Products purchased in Yukon Territory, Nunavut, Northwest Territories, Hawaii, or Alaska are not covered by this limited warranty. Products purchased in these States, provinces, or territories are sold AS IS without warranty or condition of any kind (including, without limitation, any implied warranties or conditions of merchantability or fitness for a particular purpose) and the entire risk of as to the quality and performance of the products is with the purchaser, and in the event of a defect the purchaser assumes the entire cost of all necessary servicing or repair.

What this limited warranty covers and for how long

Products covered by this limited warranty have been tested and inspected prior to shipment and, subject to the provisions of this warranty, Glen Dimplex Americas Ltd. (herein called Glen Dimplex Americas) warrants such products to be free from defects in material and workmanship in respect of the heater components of the Product for a period of 24 months from the date of the first purchase of the Product.

This limited warranty period also applies to any implied warranties that may exist under applicable law. Some jurisdictions

do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to the purchaser.

What this limited warranty does not cover

This limited warranty does not apply to Products that have been repaired (except by Glen Dimplex Americas or its authorized service representatives) or otherwise altered. This limited warranty does further not apply to defects resulting from misuse, abuse, accident, neglect, incorrect installation, improper maintenance or handling, operation with an incorrect power source, fire or other circumstance outside of Glen Dimplex Americas's control including, without limitation, an Act of God.

What you must do to get service under this limited warranty

Defects must be brought to the attention of Glen Dimplex Americas Technical Service by contacting 1-888-346-7539). Please have proof of purchase, catalogue/model and serial numbers available when calling. Limited warranty service requires a proof of purchase of the Product.

What Glen Dimplex Americas will do in the event of a defect

In the event the Product or part covered by this limited warranty is proven to be defective in material or workmanship during, in the Two Year Warranty period, as applicable, you have the following rights:

 Glen Dimplex Americas will in its sole discretion either repair or replace such defective Product or part without charge. If Glen Dimplex Americas is unable to repair or replace the Product or part, or if repair or replacement is not commercially practicable or cannot be timely made, Glen Dimplex Americas may, in lieu of repair or replacement, choose to refund the purchase price for the Product or part.



- Limited warranty service will be performed solely by dealers or service agents of Glen Dimplex Americas authorized to provide limited warranty services.
- · For products other than surrounds (mantels) and trims, this 2 year limited warranty entitles the purchaser to on-site or in-home warranty services. Accordingly, Glen DImplex Americas will be responsible for all labour and transportation associated with repairing or replacing the product or part except as follows: (i) charges which may be levied for travel costs incurred to travel to the purchaser's site where the product is located if the purchaser's site is beyond 30 miles (48 km) from the closest service depot of Glen Dimplex Americas dealer or service agent: and (ii) the purchaser is solely responsible for providing clear access to all serviceable parts of the product.
- Glen Dimplex Americas will not be responsible for, and the limited warranty services shall not include, any expense incurred for installation or removal of the Product or part (or any replacement Product or part) or any labour or transportation costs. Such costs shall be the purchaser's responsibility.

What Glen Dimplex Americas and its dealers and service agents are also not responsible for:

IN NO EVENT WILL GLEN DIMPLEX AMERICAS, OR ITS DIRECTORS, OFFICERS, OR AGENTS, BE LIABLE TO THE PURCHASER OR ANY THIRD PARTY, WHETHER IN CONTRACT, IN TORT, OR ON ANY OTHER BASIS, FOR ANY INDIRECT, SPECIAL, PUNITIVE,

EXEMPLARY, CONSEQUENTIAL, OR INCIDENTAL LOSS, COST, OR DAMAGE ARISING OUT OF OR IN CONNECTION WITH THE SALE, MAINTENANCE, USE, OR INABILITY TO USE THE PRODUCT, **EVEN IF GLEN DIMPLEX AMERICAS** OR ITS DIRECTORS, OFFICERS, OR AGENTS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH LOSSES, COSTS OR DAMAGES, OR IF SUCH LOSSES, COSTS, OR DAMAGES ARE FORESEEABLE. IN NO EVENT WILL GLEN DIMPLEX AMERICAS, OR ITS OFFICERS, DIRECTORS, OR AGENTS BE LIABLE FOR ANY DIRECT LOSSES. COSTS, OR DAMAGES THAT EXCEED THE PURCHASE PRICE OF THE PRODUCT.

SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO THE PURCHASER.

How State and Provincial law apply

This limited warranty gives you specific legal rights, and you may also have other rights which vary from jurisdiction to jurisdiction. The provisions of the United Nations Convention on Contracts for the Sale of Goods shall not apply to this limited warranty or the sale of Product covered by this limited warranty.

1-888-346-7539 | www.dimplex.com

In keeping with our policy of continuous product improvement, we reserve the right to make changes without notice.



Enhancing the moments that matter in life