



bestchoiceproducts






# 10ft Pop-Up Canopy

SKY2610 + SKY3735 + SKY4944 + SKY5765 + SKY5766

SKY3734 + SKY3736 + SKY5769

Ver. 2


## PARTS

<p><b>A</b> CANOPY</p>  <p>1 PC</p>	<p><b>B</b> ROPE</p>  <p>4 PCS</p>	<p><b>C</b> STAKE</p>  <p>8 PCS</p>
---	--	---


## ⚠ WARNING

- Be careful not to pinch hands or appendages during assembly.
- It is recommended that you use the ropes and stakes to secure the canopy.
- Canopy should not be left up in the rain. This product is not intended to withstand constant rain or inclement weather.
- This product is not intended to withstand periods of extreme/high wind or inclement.
- When not in use, this product should remain closed and stored away to avoid potential damage.

**1** With two people, pull canopy apart diagonally.



**2**




2 PERSON ASSEMBLY



UP TO 10 MIN. ASSEMBLY

**3**



**4**

