


SIMPLIHOME®

Skyler / Rhonda / Glenna

20W D Side Table

MODEL # AXCSKY-10-MRB-XXX



brooklyn + max™

WyndenHall™
HOME DECOR




Claim Your Free Gift

Your opinion pays: Earn a gift!

Review your purchase and receive a gift.* It could be a gift card, Simpli Rewards points, or another special reward.



CLAIM YOUR REWARD NOW!




simpli-home.com/get-free-gift



**Offer valid for reviews posted within 30-days of purchase.*

SIMPLIHOME®

For fastest customer service



1. Open your phone's camera.
1. Point your phone's camera at the QR code to scan.
2. Click on the pop up.
3. You'll be taken to our customer service page.
4. Fill the form with your order information and issue.
5. Submit form.
6. A customer service associate will contact you.

Other ways to contact us...



Email Us

customerservice@simpli-home.com



Visit Us

Visit our site directly at
www.simpli-home.com



Call Us

1-866-518-0120
Monday to Friday
9am to 5pm EST

***If you've purchased from a retailer and you wish to return the product, please contact the retailer directly.**

Care & Maintenance

This furniture is designed for indoor use.

Marble tops are factory polished to a smooth gloss finish and are sealed for added protection. In order to maintain the surface and keep it looking fresh and natural, we recommend the following procedures:

- For regular cleaning, use a damp cloth with warm water, rinse and dry thoroughly to prevent streaks
- Wipe off any spills immediately
- Never use abrasive cleaners or rough cleaning pads, these types of cleaners can etch or dull stone surfaces
- If necessary, a soft buffing pad can be used


To help protect your metal furniture, follow these steps:

- Use a humidifier, preferably one with an automatic control system that can sense the humidity level and adjust itself accordingly
- Dust with soft dry cloth
- Wipe up spills promptly
- Clean with a dry cloth
- Do not use abrasive cleaners, chemical solvents, strong detergents, cleaners with bleach, and furniture polish
- Use soft felt base coasters, placemats to help prevent scratches
- Keep furniture out of direct sunlight, which can cause cracking or roughness on the protective layer
- If it can be avoided, do not put furniture near heating vents
- Keep the furniture 3 to 4 inches away from the wall, giving heat and air space to circulate

Pre-Assembly Information


Part Description

A



TOP
QTY 1

B



BASE
QTY 1

Hardware Description

1



ALLEN KEY BOLT
M6 X 15 mm
QTY 4

2



WASHER
Ø 17 / Ø 6.5 x 1 mm
QTY 4

3




LOCK WASHER
Ø 10 / Ø 6.5 x 2 mm
QTY 4

4




ALLEN KEY
4 mm
QTY 1

Components – Key Diagram




Assembly

Step 1



1. Place Top (A) upside down on a flat, smooth surface.
2. Place the Base (B) on the Top (A) and align the holes.
3. Use Allen Key Bolts (1), Washers (2) and Lock Washers (3) to attach Base (B) to Top (A).
3. Use Allen Key (4) to tighten.

Step 2



NOTE: Levelers on the bottom of the base can be adjusted if floor is uneven.