


ASSEMBLY INSTRUCTION


TV STAND

A Front Frame




1pc

E Divider Panel



2pcs

I Handle




3pcs

M Bolt
Ø1/4"x1/2"




2pcs

Q Anti-Tipping Kit




2sets

B Back Frame



1pc

F Shelf Panel



3pcs

J Bolt
Ø1/4"x1/2"




15pcs

N Metal Plate
50x17x1.5mm




8pcs

R Allen Key
M4x110x30mm




1pc

C Top Panel




1pc

G Leg




2pcs

K Bolt
Ø1/4"x1"




4pcs

O Shelf Pin
21x17x15mm




12pcs

D Bottom Panel



1pc

H Cross Bar




2pcs

L Bolt
Ø1/4"x1"




6pcs

P Bolt
Ø1/4x1/2"




4pcs




First page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


1 Attach Bolt (P) to Front Frame (A) by Allen Key (R) as below shown.




2 Attach Bolt (P) to Back Frame (B) by Allen Key (R) as below shown.




- 3** Unfold the Front Frame (A) as below shown.




- 4** Place Front Frame (A) on a non-abrasive surface like carpet or a blanket. Attach both Leg (G) and Cross Bar (H) to the Front Frame (A) by Bolt (J) as below shown.




5 Attach Back Frame (B) to Front Frame (A) by Bolt (K) as below shown.




6 Secure both Leg (G) and both Cross Bar (H) to Back Frame (B) by Bolt (J) as below shown.




- 7** Place Bottom Panel (D) on Leg (G) and Cross Bar (H) as below shown.




- 8** Insert Metal Plate (N) into the holes on the Front Frame (A) and Back Frame (B) as below shown.




- 9** Slide the Divider Panel (E) into Front Frame (A) & Back Frame (B) until to Bottom Panel (D) through the Metal Plate (N). Make sure the dividers are facing correctly as below shown.




- 10** Attach Top Panel (C) to Front Frame (A) and Back Frame (B) by Bolt (J) as below shown.



- 11** Insert Shelf Pin (O) to the holes of side panels of Front Frame (A) and Divider Panel (E). Then place Shelf Panel (F) onto the Shelf Pin (O).



- 12** Attach Handle (I) to the doors of Front Frame (A) using Bolt (L) and Allen Key (R) as below shown.




13 *NOTE: WE RECOMMEND THAT YOU ATTACH THE PRODUCT TO YOUR WALL AS A SAFETY PRECAUTION USING ANTI-TIPPING KIT (Q) AS BELOW INSTRUCTION.

Attach 2pcs mounting plate of Anti-Tipping Kit (Q) to the holes on Back Frame (B) by using Bolt (M), making sure the Mounting Plate extend DOWNWARD.

Drill 2 holes in your wall approximately 2" (Inches) BELOW the corresponding positions of Mounting Plate and insert Wall Anchor as shown.

*NOTE: You may need to tap LIGHTLY with a rubber mallet.

Now connect the corresponding Mounting Plate With Connection Strap and tighten as described before locking in place.



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.