

SAFETY INFORMATION

Released Date: 2026-05-13

Please read and understand this entire manual before attempting to assemble, install or operate the product.


WARNING

- RISK OF ELECTRIC SHOCK - Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.
- RISK OF FIRE - Use bulbs specified by the markings and/or labels on the fixture.

CAUTION

- For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.
- Turn off electricity to fixture before replacing the bulb(s).

TOOLS REQUIRED



CARE OF TIFFANY STYLE SHADE

A new Tiffany lamp shade has an oil film applied to the shade that protects the Tiffany shade from scratches during shipment. If the oil applied is too heavy you can remove the excess oil film with a paper towel. Gently wipe away the excess oil.

For general cleaning of Tiffany shades use a gentle lemon oil-based furniture polish applied to a soft cloth and wipe gently.


If a white powder appears on the soldered joints of the Tiffany shade this is a normal oxidation process. Use a small amount of lemon oil or mineral oil applied directly to oxidized areas and the soldered area will return to like new.

CARE AND MAINTENANCE


- Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage the finish.

If you need further assistance call Quoizel Customer Care at 1-800-645-3184 (9:00am - 5:00pm EST), or visit us on-line at www.quoizel.com.

PACKAGE CONTENTS




MOUNTING HARDWARE




INSTALLATION

OPTION 1: PENDANT


1 Install Nipple with Hex Nut




2 Install Spacer Tube, Check Ring and Fixture Loop



3 Tighten Hex Nut Inside of Ceiling Canopy




4 Install Fixture Chain




OPTIONAL: Adjust Chain as desired, using pliers and soft cloth (neither included).

Suggested chain length for Ceiling height:
8 feet ceiling: use 15 links of chain and 2 quick links
9 feet ceiling: use 25 links of chain and 2 quick links
10 feet ceiling: use 35 links of chain and 2 quick links.




5 Pull Supply Wires

Pull the supply wires with ground wire through the chain alternate links.



6 Install Crossbar



7

Wiring

White wire from supply

Ribbed side of wire from fixture identified with the label "N"

Black (or red) wire from supply

Smooth side of wire from fixture identified with the label "L"

Ground wire from supply

Ground wire from fixture identified with the label "G"

Green ground wire

8

Install Ceiling Canopy

9

Install Bulbs

Install three correct bulbs referring to fixture markings and/or labels for maximum wattage.

Recommended Bulb Type (not included):

BULB BASE TYPE
Medium (E26)

100W
MAX
BULB TYPE
TYPE A

Your installation is now complete! Restore electricity and save this sheet for future reference.

OPTION 2: SEMI-FLUSH

* Set aside (1) Fixture Loop, (1) Fixture Chain and (2) Quick Links since they are not required for the semi-flush installation.

A Fixture Loop
x 1

FF Quick Link
x 2

GG Fixture Chain
x 1


1

Separate Ceiling Canopy


2

Install Nipple with Hex Nut


3 Install Spacer Tube, Check Ring and Ceiling Canopy




4 Install Crossbar




5 Wiring



6 Install Ceiling Canopy



7 Install Bulbs



Install three correct bulbs referring to fixture markings and/or labels for maximum wattage.

Recommended Bulb Type (not included):


BULB BASE TYPE
Medium (E26)


BULB TYPE
TYPE A

Your installation is now complete! Restore electricity and save this sheet for future reference.