


ASSEMBLY INSTRUCTION


MODERN TABLE LAMP

A Lamp Body




1pc

B Lamp Base




1pc

C Accessory




1pc

D Flat Washer
Ø19xØ4.5x1.5mm




1pc

E Lock Washer
Ø19xØ15x1.5mm



1pc

F Lamp Shade
Ø90x70mm




1pc

G Ring
Ø41x14.5mm




1pc

H Bulb



1pc




IMPORTANT SAFETY INSTRUCTIONS


THIS PENDANT LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


1 Assemble Lamp Body (A) to Lamp Base (B) using Accessory (C), Flat Washer (D) & Lock Washer (E), then you can adjust the Accessory (C) to what angle you want.



2 Take off the Ring (G) from Lamp Body (A).



- 3** Assemble the Lamp Shade (F) to the lamp holder of Lamp Body (A) using Ring (G) to tight, then assemble Bulb (H) to the lamp holder tightly.



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.