

ASSEMBLY INSTRUCTION

SPACE SAVER







This pages lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

Remark: The max weight capacity of glass shelves are 13lbs.


First, assemble Side Lower Frame (C) to Side Upper Frame - LSF (A) & Side Upper Frame - RSF (B), using Bolt (I) by Allen Key (L). Second, assemble Leveler (K) to the bottom of Side Lower Frame (C) as below shown.




First, assemble Shelf Frame (D) to Side Upper Frame - LSF (A) & Side Upper Frame - RSF (B), using Bolt (I) by Allen Key (L) as below shown.




Assemble Cross Bar (E) to Side Upper Frame - LSF (A) & Side Upper Frame - RSF (B), using Bolt (I) by Allen Key (L) as below shown.




Assemble Upper Connect Bar (F) to Side Upper Frame - LSF (A) & Side Upper Frame - RSF (B), using Bolt (I) by Allen Key (L) as below shown.



First, assemble Lower Connect Bar (G) to Side Lower Frame (C) by Allen Key (L). Second, assemble Sucker (K) to each Shelf Frame (D) then put Shelf Board



Remark: Drill a hole on the wall, assemble the Wall Anchor (M) into the hole, then using Wood Screw (N) to lock the Space Saver with the Wall Anchor (M) by



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.

4