











ASSEMBLY INSTRUCTION

E765-30 COCKTAIL TABLE

A Top Panel  1PC	B Drawer  1PC	C Side Frame  2PCS	D Long Cross Bar  2PCS
E Bottom Cross Bar  2PCS	F Top Cross Bar  2PCS	G Bolt $\frac{1}{4}" \times \frac{1}{2}" \times \varnothing 15$  34PCS	H Bolt $\frac{1}{4}" \times 1-\frac{1}{4}" \times \varnothing 15$  8PCS
I Allen Wrench $\frac{1}{4}"$  1PC			




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

***Do not tighten screws & bolts until the entire unit is completely assembled.


1

Attach Top Cross Bar (F), Long Cross Bar (D) and Bottom Cross Bar (E) to the Side Frame (C) by using Bolt (G) and Allen Wrench (I) as shown.




2

Attach Drawer (B) to the metal base by using Bolt (H) and Allen Wrench (I) as shown.



3

Attach Top Panel (A) to the metal base by using Bolt (G) and Allen Wrench (I) as shown.



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.