

Assembly Instruction




ITEM NO. U2590-17R-GRY | 3A

(VALE RAF CHAISE - GRAY)


ITEM NO. U2590-20L-GRY | 3A

(VALE LAF LOVESEAT - GRAY)

PARTS LIST

NO	COMPONENT	SKETCH	SOFA	CHAISE
A	LOVESEAT		1 PC	N/A
B	CHAISE		N/A	1 PC
C	WOODEN LEG H175mm		4 PCS	5 PCS


HARDWARE LIST

NO	COMPONENT	SKETCH	SOFA	CHAISE
1	PLASTIC WASHER D47mm		4 PCS	5 PCS

To assemble the loveseat, please follow the following steps but do not tighten all bolts:



Sofa (A)




Chaise (B)

Step 1 :

Take the parts out from zipper pouch of bottom product.

Step 2 :


Tighten wooden leg (C) with plastic washer (1) by turning it clockwise direction. Repeat the same method until all wooden leg (C) been assembled.



Step 4 :

Connect the loveseat and chaise with hooks the 2 sets of iron corner brackets together. Please refer as above diagram.

Completed



FOR LEATHER and P.U Cleaning (Code "X")

Clean by lightly brushing and vacuuming only to remove dust and particles buildup. Water -based foam cleaner or solvent based cleaning agents of any kind may cause excessive shrinking, staining or distortion of the surface pile and, therefore, should not be used.

FOR FABRIC Cleaning (Code "WW")

Use water-based agents only.
Do not use solvents.
Gently remove stains by blotting or hang washing.
Do not use excessive brushing or rubbing.