

# **Rh Riviera 24cm Frypan**

**RH03804**

Please retain instructions for future reference.

## **Care and use**

Before first use, hand-wash the cookware thoroughly. This cookware is suitable for all hobs, including induction, and can be used in domestic ovens up to 220°C (Gas Mark 7). For optimum energy efficiency, always place the cookware on hob rings that match the base size, and ensure flames do not extend over the sides or handles. To maintain and extend the lifespan of your cookware, it is recommended to use silicone, wooden, or nylon utensils; metal utensils should be avoided. Do not overheat the cookware or allow it to boil dry, and never leave it unattended while in use. Please note that the non-stick coating may discolour over time, but this does not affect the performance of the cookware. When using on ceramic hobs, always lift the cookware to move it rather than dragging it across the surface to avoid damage. Screws may loosen with time, so periodically check and carefully retighten them with a screwdriver. Always allow the cookware to cool before cleaning, as it is not dishwasher safe. Hand-wash with a mild detergent and a nonabrasive sponge, rinse, and dry thoroughly before storing; never store the cookware while wet. Always use heat-resistant oven gloves when moving the cookware and never expose hot cookware to cold liquids. If any damage is evident, discontinue use and dispose of the cookware safely.

Made in **China**.

Manufactured by: UP Global Sourcing UK Ltd, Address: Victoria Street, Oldham, Manchester OL9 0DD. **UK**.

Ultimate Products Europe Ltd, Address: 19 Baggot Street Lower, Dublin, D02 X658. **ROI**.