



YOSEMITE RECTANGLE DINING TABLE ASSEMBLY INSTRUCTIONS




A. TABLE TOP 1PC




B. EXTENSION 1PC




C. LEGS 2PCS



D. CROSS BAR 1PC



E. RAIL LEFT 1PC



F. RAIL RIGHT 1PC







TABLE ASSEMBLED



HARDWARE ENCLOSED IN BOX


1	HEX BOLT M8 x 50 MM	12 PCS	2	HEX BOLT M8 x 60 MM	06 PCS	3	ALL THREAD BOLT M8 x 45 MM	01 PC	4	FLAT WASHER M9/22	16 PCS	5	SPRING WASHER M9/11	16 PCS
														
6	HEX NUT M8	02 PCS	7	HALF MOON WASHER	02 PCS	8	SPANNER N13	01 PC	9	SOCKET WRENCH M8	01 PC	10	FLAT WASHER M9/22	02 PCS
														



Not provided


STEP 1:

FASTEN THE RAILS (E),(F) WITH THREAD BOLT (3)
WASHERS (10) AND NUTS (6).




STEP 2:

ATTACH THE "X" BRACE TO THE TABLE TOP (A),
FASTEN WITH BOLTS (2), WASHERS (4),(5).




STEP 3:

INSERT THE LEG (C) TO THE TOP BOTTOM SIDE OF THE TABLE (A). FASTEN THE LEG (C) WITH BOLTS (1), AND WASHERS (4),(5).




STEP 4:

INSERT THE CROSS BAR (D) TO "X" BRACE. FASTEN THE OTHER LEG (C) TO THE TABLE, WITH BOLTS (1),(2) WASHERS (4), SPRING WASHERS (5) AND HALF MOON WASHER (7).





STEP 5:

FASTEN THE CROSS BAR (D) WITH BOLTS (2),
WASHERS (4), SPRING WASHERS (5).




STEP 6:

TO ADD EXTENSION LEAF, SEPARATE TABLE HALVES
BY
UN COUPLING, BRACKETS ON UNDERSIDE OF TABLE
AND PULL APART.





UNLOCK

STEP 7:
ATTACH EXTENSION (B) TO THE TABLE TOP (A).



STEP 8:
PUSH TABLE HALVES BACK TOGETHER AND RECOUPLE BRACKETS ON UNDERSIDE OF TABLE.



LOCK

ASSEMBLY COMPLETE.