




BEST CHOICE
PRODUCTS



INSTRUCTION MANUAL

Set of 4 Rechargeable
Infrared Laser Tag Blasters



**BEST CHOICE
PRODUCTS**

As shoppers, we're always trying to find the perfect balance between quality & value. At BCP, we believe we've achieved that. Our diverse catalog of everyday essentials is tailored especially to our customers & guaranteed to hit that sweet spot of high quality & low price.

— Always. —

! NOTICE

- Avoid exposure to direct sunlight and excessive heat.
- Do not immerse product in water.
- Do not alter this product in any way as it may result in personal injury, product failure, and property damage.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with manufacturer's instructions as this could void the product warranty.
- Only use the provided adapter, using any other adapter may damage the equipment.
- This product does not involve actual lasers; it uses infrared technology to project an invisible beam.
- This product is intended for residential use only.



8 YEARS
OLD AND UP



1 PERSON
ASSEMBLY




UP TO 1 MIN.
ASSEMBLY

! WARNING

- Adult supervision is recommended.
- Only use or replace the battery and charger specified by the manufacturer.
- Do not submerge this product in water or expose to moisture.
- Do not place this product near or next to a heat source: fire, electronic heating devices, etc.
- Do not strike, drop, or place heavy objects on the blasters or charging stations.









BLASTER DIAGRAM



- **Life indicators (3):** Each life indicator represents 3 health points (9 total)
- **Low Battery:** The 3 life indicators will flash slowly to indicate that the blaster has low battery
- **Max Strike Distance:** 130 Feet




OPERATING INSTRUCTIONS

- 1** Switch the blaster on. The blaster will default to single shot mode.
- 2** Press the team selection button to toggle between teams. There are 4 colors to represent possible teams—Blue, red, green, and white. You cannot hit your own team. A player cannot change teams during a game.
- 3** Press the Fire-Type Selection button to toggle between four firing modes:

Fire-Type Selection	Single	Laser	Repeating	Plasma
Shots				
Health reduced by each shot				

When you run out of ammo, press the reload button under the grip to reload.

- 4** Aim and fire at an opponent's blaster to register a hit. Once hit, the life indicator will reduce accordingly and the blaster will vibrate and emit a sound. Each life indicator will show a different level of health:


- 1 health point lost =  (Slow Blinking)
- 2 health points lost =  (Fast Blinking)
- 3 Health points lost =  (Light will go dark)

When all life indicators reach 0, the speaker will play 'Game Over,' all indicators will be dark and you will be unable to fire anymore.

RESET BLASTER:


- A player cannot change teams or reset a blaster during a game.
- Press the team selection button to change your team before a game.
- To reset a blaster, switch the blaster off and on again.

CHARGING DIAGRAM



NOTE: Only use the provided adapter, using any other adapter may damage the equipment.

- A blaster has a run time of 6 hours on one full charge, for regular play.
- To set up the charging station, plug the round end of the power adapter into the adapter receiver, and the other end into a wall outlet. (see charging station diagram)
- To charge a blaster, insert it into one of the four charging ports. Press the blaster all the way down to connect the charging ports. All 4 blasters can be charged at the same time.
- When charging begins, the blasters light will shut off. The status light on the blaster will circulate twice.
- The adapter light will turn 'Red' when powered on.
- Allow 1.5 to 2 hours to charge. When charging is complete, all lights will go out.



TROUBLESHOOTING

Issue	Cause	Solution
Failure to hit opponent	Opponent is too far away	Shorten your distance from your opponent
	Receiver is inaccessible	Aim and fire at your opponent's blaster
	After switching blaster mode, the charges were not reloaded	Press the reload button on the bottom of the handle
Product is not charging	Power adapter is not secure or broken	Check that both ends of the adapter are connected
		Make sure the outlet works.
	Blaster is not fully secure in the docking station	Firmly insert the blaster until you hear an audible click
		Ensure the red light is on to indicate the unit is receiving power
The power switch is in neither the On or Off position	Replace adapter	
Blasters Operate Automatically	Low Battery	Adjust the power switch to either the On or Off position
	Overexposure to sunlight	Charge the battery
	Competing infrared transmission from other devices, such as TV remotes	Block the sunlight or play in an area without direct sunlight
		Stop using or move away from competing infrared devices

NOTE: If normal operation of the product is disturbed or interrupted, strong electro-magnetic interference may be the cause. Reset the product by turning it off completely, then back on.

MAINTENANCE AND REPAIR

- If this item will not be used for an extended period, remove all batteries to prevent degradation and damage.
- Clean off dust with a dry cloth.
- Do not leave this product exposed to excessive heat or sunlight.

FCC COMPLIANCE STATEMENT

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This product may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Responsible party (contact for FCC matters only):

Quality Control Dept.

15101 Red Hill Ave.

Tustin, CA 92780



HELP CENTER



Question about your product? We're here to help. Visit us at:

help.bestchoiceproducts.com



Chat Support



Product Inquiry



Orders FAQ



Product Assembly



Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledged by Best Choice Products as undamaged.

© Best Choice Products, Inc. All rights reserved. Distributed by Best Choice Products, Inc. Tustin, CA 92780



WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.