




BEST CHOICE
PRODUCTS



INSTRUCTION MANUAL

8-Piece Kids Garden Tool Set

⚠ WARNING
ADULT ASSEMBLY REQUIRED

⚠ WARNING
CHOKING HAZARD - Small parts.
Not for children under 3 years old.

! NOTICE Please retain these instructions for future reference.

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws and knobs before use.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- Fasten screws loosely during initial assembly. Do not fully tighten screws until the item is completely assembled.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Be aware that moving parts can injure, crush, and cut.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.
- This product is intended for residential use only.

TOOLS REQUIRED



75 LBS
CAPACITY



1 PERSON
ASSEMBLY








3 YEARS
OLD AND UP



UP TO 45 MIN.
ASSEMBLY

HARDWARE



PARTS

A


TRAY



1 PC

B


SUPPORT BRACKET



2 PCS

C


LEG



2 PCS

D


CENTER SUPPORT



1 PC

E


AXLE SHAFT



2 PCS

F

AXLE ROD



1 PC

G


WHEEL



1 PC

H

HANDLE




2 PCS

PRODUCT ASSEMBLY


1

Place **part A** tray upside down, then attach two **part H** handles and two **part C** legs with four **part 2** bolt & nut sets.



2


Attach the **part D** center support with two **part 3** bolt & nut sets.



PRODUCT ASSEMBLY


3

Place the assembly upright, then attach two **part B support brackets** with two **part 3 bolt & nut sets**.



4


Attach one **part E axle shaft** with one **part 1 bolt & nut set**.



PRODUCT ASSEMBLY


5

Align the **part G wheel** with the assembled axle shaft and then secure it with two **part 5 gaskets** and a **part F axle rod**.



6


Attach the remaining **part E axle shaft** with one **part 1 bolt & nut set**.



PRODUCT ASSEMBLY


7

Insert two **part 4** stoppers.



8

Flip the assembly upright and enjoy.





HELP CENTER



Question about your product? We're here to help. Visit us at:

— bestchoiceproducts.com/pages/help —



Chat Support



Product Inquiry



Orders FAQ



Product Assembly



Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

© Best Choice Products, Inc. All rights reserved. Distributed by Best Choice Products, Inc. Newport Beach, CA 92660



WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.