












ASSEMBLY INSTRUCTION


CONSOLE WITH WINE RACK

A Console Body	B Side Leg	C Middle Leg	D Cross Bar
			
1pc	4pcs	1pc	1pc
E Bolt Ø1/4"x38mm	F Bolt Ø1/4"x15mm	G Lock Washer Ø1/4"x10mm	H Flat Washer Ø1/4"x16mm
			
1pc	14pcs	6pcs	6pcs
I Allen Key M4	J Anti-Tipping Kit		
			
1pc	1set		




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


1 Attach Cross Bar (D) to Side Leg (B) & Middle Leg (C), using Bolt (F) & Bolt (E) by Allen Key (I) as below shown.



2 Attach Side Leg (B) & Middle Leg (C) to Console Body (A), using Bolt (F), Lock Washer (G) and Flat Washer (H) by Allen Key (I) as below shown.



- 3** Remark: there is a tip restraint kit provided on the back of this product. Please read the instruction thoroughly and install immediately when placed in home. To prevent tip over, the product must be attached to wall.



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.