



ITEM NAME/NOM D'ITEM: TOGE DINING TABLE
ITEM# /NO. ITEM: 704239


PARTS LIST/LISTE DES PIÈCES

(1)	(2)	(3)
 x1	 x4	A.  M6x40 x12 B.  Screw6x25 x8 C.  7x16x1 x20 D.  x1 E.  Plastic cap x12


ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE

Do not FULLY TIGHTEN the screws or nuts for any step until all are in place.

I




II




Tighten to 50–70%

III




Tighten to 100%

IV



Tighten to a level of 50 - 70% of the full capacity. In the final step, tighten it fully

V



Please use the attached adjustable footglides to level the table on an uneven surface.

