


# FLEXSTEEL®

## Power Recliner with Power Headrest, Lumbar, Heat & Massage

### IMPORTANT NOTE


Read these instructions carefully and familiarize yourself with each procedure before assembling the furniture. Check that you have all the component parts and familiarize yourself with each part before proceeding.

Take all the fittings out of the plastic bag and separate them into groups. Ensure you have enough space to lay out all the parts before assembly. To prevent damage to the parts, we recommend that you assemble the unit on a soft, level surface.




### Part List

A. Back  
1 piece



B. Seat  
1 piece



C. Left Wing  
1 piece



D. Right Wing  
1 piece



E. Transformer  
1 piece



### Assembly Instructions

#### STEP 1

Detach the Transformer (E) and the Wings (C D) from the bottom of the Seat (B). (See Figure 1.)




Figure 1

#### STEP 2

Attach the Back (A) to the Seat (B) and Wings (C D) to the Back (A). Ensure the latches fit well. (See Figure 2.)




Figure 2

#### STEP 3

Zip the fabric on the bottom of the Back (A) with the back of the Seat (B). (See Figure 3.)




Figure 3

#### STEP 4

Flip up the back flap, connect the Headrest, Switch and Air Massage cables between the Back (A) and the Seat (B). (See Figure 4.)




Figure 4

#### STEP 5

Fasten the back flap to the bottom of the furniture. (See Figure 5.)




Figure 5

#### STEP 6

Connect the power cable from the bottom of the Seat (B) to the Transformer (E), then plug it into a nearby outlet. (See Figure 6.)




Figure 6

### Disassembly Instructions

Unzip the zipper between Back (A) and Seat (B), then disconnect all the cables. Pull up the spring leaf in bracket, then lift Back (A) up. (See Figure 7.)





Figure 7

## Hidden Cup Holder



### IMPORTANT NOTE

- To avoid any risk of suffocation to children or pets, dispose of all plastic bags immediately.
- To ensure proper performance, occasionally check for loose hardware and tighten as needed.
- If the reclining functions are not working properly, check for loose cable connections before contacting the retailer.