




ITEM NAME / NOM D'ITEM: ISKA DINING CHAIR
ITEM # / NO.ITEM: 704049/704050


PARTS LIST / LISTE DES PIÈCES	
(1)	(2)
 ×1	 ×4

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE

I



II



Please use the attached adjustable footglides to level the chair on uneven surface.