

**MODELS 350DA, 350ADA, 350ASTDA, 450DA  
375DA, 375ADA, 375ASTDA, 475DA, 475DAV**  
Double Check/ Reduced Pressure Principle  
Detector Assemblies 2 1/2" to 12"



**REPAIR KITS**

CHECKS ONLY		COMPLETE KIT (RUBBER ONLY)	
<b>RK4-350ADA</b> REPAIR KIT 350ADA, 350ASTDA MODELS, 2 1/2" & 3" RUBBER Only		<b>RK4-375ADAC</b> REPAIR KIT 375ADA, 375ASTDA MODELS, 2 1/2" & 3" Checks & Relief Valves	
<b>INCLUDES</b>	<b>DESCRIPTION</b>	<b>INCLUDES</b>	<b>DESCRIPTION</b>
RK34-950XLR	REPAIR KIT for MODEL 950/975, 3/4"	RK34-975XLR	REPAIR KIT for MODEL 950/975, 3/4"
RK4-350	REPAIR KIT for MODEL 350A/375A, 2 1/2" & 3"	RK4-350	REPAIR KIT for MODEL 350A/375A, 2 1/2" & 3"
		RK212-375R	REPAIR KIT for MODEL 375 REL. VALVE 2 1/2" & 3"
<b>RK212-350DA</b> REPAIR KIT 350DA Models 2 1/2" & 3" RUBBER Only		<b>RK212-375DAC</b> REPAIR KIT 375DA Models, 2 1/2" & 3" Checks & Relief Valves	
<b>INCLUDES</b>	<b>DESCRIPTION</b>	<b>INCLUDES</b>	<b>DESCRIPTION</b>
RK34-950XLR	REPAIR KIT for MODEL 950/975, 3/4"	RK34-975XLR	REPAIR KIT for MODEL 950/975, 3/4"
RK212-350	REPAIR KIT for MODEL 350/375, 2 1/2" & 3"	RK212-350	REPAIR KIT for MODEL 350/375, 2 1/2" & 3"
		RK212-375R	REPAIR KIT for MODEL 375 REL. VALVE 2 1/2" & 3"
<b>RK4-350DA</b> REPAIR KIT ALL DA MODELS, 4" RUBBER Only		<b>RK4-375DAC</b> REPAIR KIT ALL DA MODELS 4" Checks & Relief Valves	
<b>INCLUDES</b>	<b>DESCRIPTION</b>	<b>INCLUDES</b>	<b>DESCRIPTION</b>
RK34-950XLR	REPAIR KIT for MODEL 950/975, 3/4"	RK34-975XLR	REPAIR KIT for MODEL 975, 3/4"
RK4-350	REPAIR KIT for MODEL 350(A)/375(A), 4"	RK4-350	REPAIR KIT for MODEL 350(A)/375(A), 4"
		RK212-375R	REPAIR KIT for MODEL 375(A) Relief Valve, 4"
<b>RK6-350DA</b> REPAIR KIT ALL DA MODELS, 6" RUBBER Only		<b>RK6-375DAC</b> REPAIR KIT ALL DA MODELS 6" Checks & Relief Valves	
<b>INCLUDES</b>	<b>DESCRIPTION</b>	<b>INCLUDES</b>	<b>DESCRIPTION</b>
RK34-950XLR	REPAIR KIT for MODEL 950/975, 3/4"	RK34-975XLR	REPAIR KIT for MODEL 975, 3/4"
RK6-350	REPAIR KIT for MODEL 350(A)/375(A), 6"	RK6-350	REPAIR KIT for MODEL 350(A)/375(A), 6"
		RK212-375R	REPAIR KIT for MODEL 375(A) Relief Valve, 6"
<b>RK8-350DA</b> REPAIR KIT ALL DA MODELS, 8", 10" & 12" RUBBER Only		<b>RK8-375DAC</b> REPAIR KIT ALL DA MODELS 8" & 10" Checks & Relief Valves	
<b>INCLUDES</b>	<b>DESCRIPTION</b>	<b>INCLUDES</b>	<b>DESCRIPTION</b>
RK34-950XLR	REPAIR KIT for MODEL 950/975, 3/4"	RK34-975XLR	REPAIR KIT for MODEL 975, 3/4"
RK8-350	REPAIR KIT for MODEL 350(A)/375(A), 8" - 12"	RK8-350	REPAIR KIT for MODEL 350(A)/375(A), 8" & 10"
		RK8-375R	REPAIR KIT for MODEL 375(A) Relief Valve, 8" & 10"

**#2 CHECK ASSEMBLIES FOR DETECTOR ASSEMBLIES**

SIZE	MODEL	#2 CHECK ASSY	MODEL	#2 CHECK ASSY
2 1/2" & 3"	350ADA / 375ADA	3509-300B		
2 1/2" & 3"	350DA / 375DA	3507DA-300	350ADA/375ADA	3509-300B
2 1/2"	350ASTDA / 375ASTDA	3507STDA-300B		
3" & 4"	350ASTDA / 375ASTDA	3509STDA-300B		
4"	350DA(A) / 375DA(A)	3509-300B	450DA/475DA/475DAV	3509-300B
6"	350ASTDA / 375ASTDA	3510STDA-300B		
6"	350DA(A) / 375DA(A)	3510-300B	450DA/475DA/475DAV	3510-300B
8"	350DA, 350ADA	3512DA-300	450DA/475DA/475DAV 350ADA, 375DA(A)	4512DA-300
8"	350ASTDA / 375ASTDA	3511STDA-300B		
10"	350DA	3512DA-300		
10"	350ASTDA / 375ASTDA	3511STDA-300B		
12"	350DA (#1 CHECK)	3513DA-300A	350DA	3513DA-300B

**BULKHEAD FITTINGS**

ITEM NO.	DESCRIPTION	BHF1BXL-100	BHF1CXL-100	BHF2BXL-100	BHF2CXL-100
1	NUT	BHF1-9-010F	BHF1-9-010F	BHF2-9-010F	BHF2-9-010F
2	WASHER	BHF1-14	BHF1-14	BHF2-14	BHF2-14
3	GASKET	BHF1-13	BHF1-13	BHF1-13	BHF1-13
4	FITTING	BHF1-19BXL-010F	BHF1-19CXL-010F	BHF2-19BXL-010F	BHF2-19CXL-010F

