

INSTRUCTION MANUAL

Elevated 9 Cube Bookshelf



As shoppers, we're always trying to find the perfect balance between quality & value. At BCP, we believe we've achieved that. Our diverse catalog of everyday essentials is tailored especially to our customers & guaranteed to hit that sweet spot of high quality & low price.

- Always.



240 LBS TOTAL CAPACITY



87 LBS CABINET TOP BOARD CAPACITY



17 LBS PER CUBE CAPACITY



ASSEMBLY



ASSEMBLY

(!) NOTICE

Please retain these instructions for future reference.

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws, and knobs before use.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- Fasten screws loosely during initial assembly. Do not firmly tighten the screws until the item is completely assembled.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- To prevent swelling or warping, wipe away any excess water on the surfaces of the product
- Be aware that some parts are heavy and have sharp edges.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.
- This product is intended for residential use only.


TOOLS REQUIRED









HARDWARE




















HARDWARE






MOUNTING HARDWARE















PARTS










1


Insert four part D dowels into two part 7 middle dividers, two dowels per divider.


Attach it to one part 6 cabinet shelf.



2


Insert four part D dowels into the two part 7 middle dividers, two dowels per divider, then attach them to a second part 6 cabinet shelf used in the previous step.





Insert two part B cam locks into the tops of the part 6 shelves, four cam locks total.


Insert two part C dowels into the side of the part 6 shelves, then attach the part 3 cabinet right side, turn the cam locks to secure, then cover each lock with one part J cam lock cover.






Insert two ${\bf part~B~cam~locks}$ into the tops of the ${\bf part~6~shelves}$, four cam locks total.

Insert two part C dowels into the side of the part 6 shelves, then attach the part 2 cabinet left side, turn the cam locks to secure, then cover each lock with one part J cam lock cover.



6

Attach the part 4 and part 5 top dividers to the "top" part 6 shelf.






Locate the part 1 cabinet top, then insert eight part A cam bolts.

8

Insert two part C dowels and two part B cam locks each into the top of the part 2, part 3, part 4, and part 5 panels, eight dowels and eight cam locks total.


Attach the part 1 top panel, then turn the cam locks to secure.

Cover each cam lock with one part J cam lock cover.



9


Attach two part 8 bottom dividers to the "bottom" part 6 shelf.



10


Insert two part C dowels each into the bottom of the part 2, part 3, and part 8 panels, eight dowels total.

Attach the part 9 cabinet bottom, then secure with eight part E wood screws.






Attach two part 11 base frame connectors to two part 12 base side frames with four part F bolts.




12




13


Attach the bottom assembly to the part 9 cabinet bottom with ten part G bolts.



If desired, use a hammer to attach three part 10 back boards with thirty-two part I wood nails.



- 1. Attach the part L mounting straps to the part 1 cabinet top with two part P small screws.
- 2. Select an appropriate location, then mark two spaces on the wall using the part L mounting straps as guides. Use a drill on the marked spaces.
- 3. Insert two part N wall anchors into the new holes in the wall. Overlap the holes with the mounting straps, then attach the cabinet to the wall by drilling two part M wall anchor screws through the part O washers, part L mounting straps and into the part N wall anchors.





BEST CHOICE PRODUCTS

Check out more great products: **bestchoiceproducts.com**

Earn points while you shop. Join today!

bestchoice products reward\$

Join | Earn | Redeem

Give your friends 15% off their first order! For each successful referral you'll receive 100 points.

bestchoiceproducts.com



Question about your product? We're here to help. Visit us at:

help.bestchoiceproducts.com













Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

© Best Choice Products, Inc. All rights reserved. Distributed by Best Choice Products, Inc. Newport Beach, CA 92660

△WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.