

HOW TO MAINTAIN YOUR DESIGN HOUSE® OUTDOOR LIGHTING

Taking care of your Design House® outdoor lighting is simple.
Follow these directions for easy everyday maintenance.




Wipe clean with a
soft, dry cloth.



Clean with a
mild detergent.



Resist using strong liquid
cleaners or abrasive cloths
or scouring pads.



Design House® has been providing quality home solutions for over 150 years.