Installation Instructions




Installation Instructions Suits 35mm to 45mm Door Thickness



Now your lock is installed, it's time to setup. Please refer to the separate User Guide supplied with your product for instructions.

Gainsborough Freestyle Manual Function



IMPORTANT

It is important not to engage the Deadlock function when there are people inside the house. Only use good quality alkaline batteries with your Gainsborough Freestyle Trilock®.

USE & CARE INSTRUCTIONS

This lockset is designed to provide the highest standard of product quality and performance. Care should be taken to ensure a long-lasting finish. When cleaning is required use a soft, damp cloth. Using lacquer thinner, caustic soaps, abrasive cleaners or polishes could damage the coating and result in tarnishing. Do not clean screen with any cleaning products containing bleach. Do not install the lock in close proximity to caustic vapours or where it may be subjected to extreme weather conditions.

WARNINGS


IMPORTANT: The accuracy of the door preparation is critical for the proper functioning and security of this product. Misalignment can cause premature wear and a lessening of security. The lock should only be serviced by a qualified technician.


Any unauthorised modifications will void your warranty and compromise your security.





Allegion Australia Freephone 1800 098 094 Freefax 1800 098 095 Email info.au@allegion.com Allegion New Zealand Freephone 0800 477 869 Freefax 0800 4 77 868 Email nzinfo@allegion.com www.allegion.co.nz












· Use of power driver is not recommended for screw installation

Fully remove the Gainsborough Freestyle prior to painting the door to avoid damaging the product's finish
 Suitable door thickness is between 35 and 45mm

NOTES: • Carefully follow these instructions when installing


· Do not overtighten screws



Step 4:

Handing of the Internal Lever

- a. Rehand the lever (if necessary), by pushing the retaining plate inside the furniture as shown. (Push through the hole on the same side as the lever.)
- b. Then swing the lever up and over to the other direction.





READY TO GET YOUR SMART HOME JOURNEY STARTED? WATCH INSTALLATION AND SET UP VIDEOS



225380_GAIH_Freestyle_Update_PDGA0079_R1_MAR_25_Installation_Instructions_Freestyle_210x297mm_FA.indd 1-2

20/3/2025 10:20 am


Installation Instructions

freestŷle


Step 5:


Handing of the External Furniture

- a. Rehand the lever (if necessary), by pushing the retaining plate inside the furniture as shown. <u>Push through the hole on the same side as the lever.</u>
 b. Then swing the lever up and over to the other direction.



Step 6: Assemble the External Furniture to the Door Install the External furniture onto the door as shown.










(


Install the Spindle


Fit the Spindle Spring to the Spindle, and then assemble through the latch into the

























Connect Door Position Sensor

Connect Door Position Sensor cable to plug on the Main cable




* Door Position Sensor sold separately

Step 4b:

Install Door Position Magnet

Drill a Ø10mm hole for the Door Position Magnet and fit magnet as shown.



TRILOCK 3

2