








# ASSEMBLY INSTRUCTION

## END TABLE WITH FAUX MARBLE TOP

<b>A</b>	Wood Top	<b>B</b>	Upper Side Panel	<b>C</b>	Under Side Panel
					
1pc		1pc		1pc	
<b>D</b>	Bolt 1/4" x 1/2"	<b>E</b>	Bolt 1/4" x 1-1/4"	<b>F</b>	Allen Wrench 1/4"
					
8pcs		1pc		1pc	




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

**\*\*\* Do not tighten screws & bolts until the entire unit is completely assembled.**


**1**

Attach Upper Side Panel (B) to Wood Top (A) by Bolt (D) and Allen Wrench (F) as shown.



**2**

Attach Under Side Panel (C) to Wood Top (A) by Bolt (D) and Allen Wrench (F). Then attach two side panels together by Bolt (E) and Allen Wrench (F) as shown.




### Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.

# ASSEMBLY INSTRUCTION


## COCKTAIL TABLE WITH FAUX MARBLE TOP

**A** Wood Top




1pc

**B** Upper Side Panel




1pc

**C** Under Side Panel




1pc

**D** Bolt  
1/4" x 1/2"




8pcs

**E** Bolt  
1/4" x 1-1/4"




1pc

**F** Allen Wrench  
1/4"



1pc




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

**\*\*\* Do not tighten screws & bolts until the entire unit is completely assembled.**


**1**

Attach Upper Side Panel (B) to Wood Top (A) by Bolt (D) and Allen Wrench (F) as shown.



**2**

Attach Under Side Panel (C) to Wood Top (A) by Bolt (D) and Allen Wrench (F). Then attach two side panels together by Bolt (E) and Allen Wrench (F) as shown.



### Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.