



ASSEMBLY INSTRUCTION

DESK


A Table Side Frame **B** Table Top **C** Table Bottom Stretcher **D** Table Top Stretcher




2PCS



1PC



1PC



2PCS

E Bolt
1/4" x 70mm



6PCS

F Bolt
1/4" x 35mm




6PCS

G L-Allen Key
4mm




1PC




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

1

Attach the Table Side Frame (A) to Table Top Stretcher (D) and Table Bottom Stretcher (C), insert the Bolt (E), turn the L-Allen Key (G) to tighten them.

**2**

Turn the assembled frame over as shown. Attach the Table Top (B) to Table Top Stretcher (D), insert the Bolt (F), turn the L-Allen Key (G) to tighten them.



Cleaning & Care

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.