








ASSEMBLY INSTRUCTION


HUTCH

A Back Panel  1 PC	B Upper Shelf  1 PC	C Divider  2 PCS	D Lower Shelf  1 PC
E Wine Rack Panel  4 PCS	F Left Side Panel  1 PC	G Right Side Panel  1 PC	H JCBC Bolt M6 x 35mm  14 PCS
I Lock Washer M6  14 PCS	J Flat Washer M6  14 PCS	K PVC Dowel M8 x 30mm  20 PCS	L Mini Fix 34mm  8 PCS
M Mini Fix Housing Ø15mm x 12mm  8 PCS	N Panhead Screw M4 x 20mm  4 PCS	O Allen Wrench M4 x 60mm  1 PC	P I-Bracket & Screw 15mm x 60mm x 2.5mm / 20mm  2 SETS
Q Anti-Tipping Kit  1 SET			




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


- 1** (i) Insert PVC Dowel (K) into predrilled holes of Back Panel (A), Upper Shelf (B), Divider (C) and Lower Shelf (D).
(ii) Attach Mini Fix (L) into predrilled holes of Upper & Lower Shelf (B & D) with screwdriver (not provided).




2 Slot in two pieces Wine Rack Panel (E) together.




3 Use PVC Dowel (K) as a guide, align and attach Divider (C) to Upper & Lower Shelf (B & D), then tighten Mini Fix Housing (M) with Allen Wrench (O).




- 4** Put Back Panel (A) on a flat surface. Use PVC Dowel (K) as a guide, align and attach Left & Right Side Panel (F & G) to Back Panel (A) and Upper & Lower Shelf (B & D) using JCBC Bolt (H), Lock Washer (I) and Flat Washer (J) with Allen Wrench (O).



- 5** (i) Fix Left & Right Side Panel (F & G) to Back Panel (A) using JCBC Bolt (H), Lock Washer (I) and Flat Washer (J) with Allen Wrench (O).
(ii) Fix Back Panel (A) to Upper & Lower Shelf (B & D) using Panhead Screw (N) with screwdriver (not provided).




- 6** Insert Wine Rack Panel (E) into the space between Upper & Lower Shelf (B & D).




More Selection Style

- 7** Put the Hutch on the top of Buffet and fix them using I-Bracket & Screw (P) with screwdriver (not provided) from behind.



8 Attach Anti-Tipping Kit (Q) to wall. Attach bracket (vertically) to wall using the long screw provided. Attach bracket (vertically) to furniture back (directly below top) with short screw. Place bracket as close to left of furniture back as possible in relation to wall stud and the desired position in the room. Move furniture to its final position. Thread the strap through the bracket, pull it tight.




Cleaning & Care

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.

ASSEMBLY INSTRUCTION


BUFFET WITH POWER OUTLET

A Buffet




1 PC

B Shelf




1 PC

C Leg




4 PCS

D Wine Rack
(Horizontal)




1 PC

E Wine Rack
(Vertical)



3 PCS

F JCBC Bolt
M6 x 60mm




8 PCS

G Lock Washer
M6



8 PCS

H Flat Washer
M6




8 PCS

I Allen Wrench
M4 x 100mm




1 PC

J Handle & 2 pcs
Screw



3 SETS

K Anti-Tipping Kit




1 SET




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

- 1** Slot in three pieces of Wine Rack (Vertical) (E) to Wine Rack (Horizontal) (D).




- 2** Attach two Leg (C) to Buffet (A) using JCBC Bolt (F), Lock Washer (G) and Flat Washer (H) with Allen Wrench (I). Then attach Shelf (B) to Leg (C) using JCBC Bolt (F), Lock Washer (G) and Flat Washer (H) with Allen Wrench (I).


**** Do not fully tighten all the bolts at this step.**




- 3** Attach the other two Leg (C) to Buffet (A) and Shelf (B) using JCBC Bolt (F), Lock Washer (G) and Flat Washer (H) with Allen Wrench (I).
**** Fully tighten all the bolts at this step.**




- 4** Stand the Buffet up on an even surface and check that it is balanced. Place the assembled Wine Rack (D & E) into the Buffet (A).



- 5** From inside, attach Handle (J) to the drawer front and doors using Screw (J) with screwdriver (not provided).



- 6** Attach Anti-Tipping Kit (K) to wall. Attach bracket (vertically) to wall using the long screw provided. Attach bracket (vertically) to furniture back (directly below top) with short screw. Place bracket as close to left of furniture back as possible in relation to wall stud and the desired position in the room. Move furniture to its final position. Thread the strap through the bracket, pull it tight.



Cleaning & Care

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.