

FACEPLATE INSTALLATION INSTRUCTIONS

SBK4F2RD-1/SABKF2RD-1/WIDF2RD/SBK4F3RD-1/SABKF3RD-1/WIDF3RD (RD3)

INSTRUCTIONS D'INSTALLATION DE LA PLAQUE FRONTALE

SBK4F2RD-1/SABKF2RD-1/WIDF2RD/SBK4F3RD-1/SABKF3RD-1/WIDF3RD (RD3)

⚠ WARNING

- Ensure the appliance is completely cool before starting installation.
- To avoid danger of suffocation, keep the packaging bag away from babies and children. Do not use in cribs, beds, carriages, or play pens. This bag is not a toy. Knot before throwing away.

⚠ AVERTISSEMENT


- Assurez-vous que l'appareil est complètement refroidi avant de commencer l'installation.
- Afin d'éviter les risques de suffocation, gardez le sac d'emballage loin des bébés et des jeunes enfants. Ne le laissez pas traîner dans les berceaux, les lits, les poussettes, ou les parcs de jeu. Ce sac n'est pas un jouet. Nouez-le avant de le jeter.

RD3 illustrated / RD3 illustrée

1

Ⓜ If equipped, remove the safety barrier and set it aside. If the unit is not equipped with a safety barrier, skip this step.


Ⓜ Si l'appareil est muni d'une barrière de sécurité, retirez-la et mettez-la de côté. Si l'appareil n'est pas muni d'une barrière de sécurité, passez à l'étape suivante.



2

Ⓜ Use the front notch-out for flat backerplates and the rear notch-out for 1 in. backerplates.

Ⓜ Utilisez l'encoche avant pour les plaques de support plates et l'encoche arrière pour les plaques de support de 1 po.



Quality System Certified To
ISO
9001-2015