

ASSEMBLY INSTRUCTION


FULL/QUEEN DABED TRUNDLE






This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare f or assembly, place the contents on a carpeted or padded area to protect them from damage.


ATTACHED CONNECTION STRAP(I), LOCK WASHER(F), FLAT WASHER(G), BOLT(E), BY ALLEN WRENCH(J), TRUNDLE FRONT PANEL(A), TRUNDLE BACK PANEL(B), AND LEFT & RIGHT PANEL (C).



2 ATTACHED CONNECTION SLATS FOR DAYBED(D).



3 ATTACHED SLATS FOR DAYBED(D), WITH SELF-TAPPING SCREW(H).





Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.

ASSEMBLY INSTRUCTION


TUFTED FULL/QUEEN DAYBED SOFA






This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare f or assembly, place the contents on a carpeted or padded area to protect them from damage.


ATTACHED LEFT ARM(A), RIGHT ARM(B), BACK RAIL (E), FRONT RAIL(F), CONNECTION STRAP(O), LOCK WASHER(K), FLATWASHER(L), BOLT(I), BOLT(H), BY ALLEN WRENCH(P).




ATTACHED LEFT ARM(A), RIGHT ARM(B), MIDDLE DRAG STRIP(R), FLATWASHER(M), BOLT(J),BY ALLEN WRENCH(Q).




3 ATTACHED LEFT MIDDLE DRAG STRIP(R), SUPPORTING FOOT(S), FLAT WASHER(M), BOLT(J), BY ALLEN WRENCH(Q)



4 ATTACHED BACK REST(C),TO (A)&(B) WITH LOCK WASHER(K) LOCK WASHER(K), FLAT WASHER(L), BOLT(J) WITH LEFT ARM(A) & RIGHT ARM(B), BY ALLEN WRENCH(P).



5 ATTACHED SLATS FOR DAYBED(D), WITH SELF-TAPPING SCREW(N).



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.