


Louver Plate Kit



⚠ WARNING

To avoid electric shock, do not energize any circuits before all internal and external electrical and mechanical clearances are checked to assure that all assembled equipment functions safely and properly.



Catalog Number	A	B	L	M	P	R	S
AVK23 AVK23SS6	3.25	3.25	2.00	1.75	2.50	2.50	---
AVK33 AVK33SS6	3.88	4.50	2.62	3.00	3.12	3.75	---
AVK34 AVK34SS6	4.75	4.50	3.50	3.00	4.00	3.75	---
AVK43 AVK43SS6	4.50	5.50	3.25	4.00	3.75	4.75	---
AVK44 AVK44SS6	5.62	5.50	4.38	4.00	4.88	4.75	---
AVK64 AVK64SS6	5.62	7.50	4.38	6.00	4.88	6.75	---
AVK66 AVK66SS6	7.88	7.50	6.62	6.00	7.12	6.75	3.56
AVK84 AVK84SS6	5.81	9.50	4.56	8.00	5.06	8.75	---
AVK86 AVK86SS6	8.19	9.50	6.94	8.00	7.44	8.75	3.72
AVK88 AVK88SS6	10.56	9.50	9.31	8.00	9.81	8.75	4.91
AVK812 AVK812SS6	15.31	9.55	14.06	8.00	14.56	8.75	7.28