

Aqua Power™

Owner's Manual

#02878



WWW.RAVESPORTS.COM

Copyright © 2018 All rights reserved. No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopy, recording, or any information storage and retrieval system, without permission in writing from the publisher. Requests should be mailed to RAVE Sports, 985 Aldrin Dr., Suite 301 Eagan, MN 55121.

Table of Contents:

Parts.....	1
Introduction	2
Safety rules & information	3
Inflation	5
Anchoring	6
Using Aqua Power	7
Other Inflator Options	8
Cleaning & storage	8
Repairs.....	9

Date Purchased: _____

Purchased from: _____

Serial Number: _____

(Serial # is located next to the inflation valve on the tube.)

Package Contents:

Qty 1- Aqua Power (#02878)

Qty 1- Spring Lock Swivel Carabiner Kit (#20940) (includes 2 sets)

Qty 1- Repair Kit

Qty 1 - Owner manual

Introduction

Thank you for purchasing a RAVE Sports® Aqua Power Mat. This Owner's Manual is presented to enhance your enjoyment of the activity and is intended to alert you to some of the potentially dangerous conditions that can arise in all water sports. It also contains important safety instructions and information about how to assemble, use and care for your product.

Please take a few minutes to read this manual before assembling and using the product. Although the product is simple to use, this manual contains important safety information that you and all users must understand to safely enjoy the Aqua Power.

Make sure that everyone who uses the product also receives proper education and supervision and understands the safety instructions and warnings presented in this manual. Be sure to save this manual for future reference.

IMPORTANT: This Aqua Power was designed to be used as a stand-alone product. Do not attempt to attach it to other products or use it in any other manner than its designed and intended use as described herein.

If you have any questions regarding this product, please call RAVE Sports at 1-800-659-0790 or visit www.ravesports.com. Please have your serial number available.

WARNING

**UNSAFE USE OF THE AQUA POWER CAN
RESULT IN PERSONAL INJURY OR DEATH.**

**TO REDUCE THE RISK OF INJURY, READ AND FOLLOW ALL
INSTRUCTIONS AND WARNINGS IN THIS MANUAL. DO NOT USE
THIS PRODUCT UNLESS YOU UNDERSTAND AND ACCEPT THE RISK
OF INJURY INVOLVED WITH THIS ACTIVITY.**

Safety Rules and Information

- Read and understand all of the information contained in this owner's manual before assembling and using your product.
- Make sure that everyone who uses the product is provided with and understands these safety rules and information.
- This is not a life saving device.
- No more than one person on the product at a time.
- The Aqua Power is designed to be used in a pool/lake with at least 4 feet (1.2m) of water depth.
- Always anchor the Aqua Power securely before it is used.
- Drowning Hazard: Never swim or play under the Aqua Power.
- Never dive off the product head first. If jumping off the product, always enter the water feet first.
- Not recommended for children under the age of six. Use the Aqua Power only under mature, knowledgeable adult supervision.

- The surface of the Aqua Power will get wet and may be slippery. Always exercise caution and common sense while using the Aqua Power. Reckless behavior may result in serious injury.
- If outdoors, never use the product in rough surface water conditions, during storms, or when there is lightning. If an unexpected storm arises while using the product, seek shelter on shore. Do not stay on the product.
- Choose a location for your product that is most protected from wind, of sufficient water depth, and free of obstructions in all directions.
- Maintain safe distance to sidewalls of pool, suspended cables and ropes or other dangerous hard objects.
- Never use the product under the influence of alcohol or drugs.
- Never use the product while tired or fatigued.
- Inspect your product for any worn, defective, or missing parts. Do not use if there are any signs of damage, wear or deterioration. Replace or repair before use.
- Never tow from a boat or other motorized vehicle.
- When not in use, secure the product against unauthorized or unsupervised use.

Liability

While every attempt is made to embody the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

Inflation

Roll out the Aqua Power on a flat surface. Make sure the area is free of sharp objects that could puncture or damage the product.

Option 1 High Speed Inflator & SUP Hand Pump

We highly recommend using the RAVE High Speed Inflator/Deflator. It will provide rapid inflation and deflation. *(Item #01083, sold separately)*



To lock open valve, depress the stem and rotate $\frac{1}{4}$ turn clockwise. To close valve, depress the stem and rotate $\frac{1}{4}$ turn counter-clockwise. The valve stem should be in the depressed position while inflating. Replace cap on valve after inflation to ensure air tight seal.



If you are using the RAVE Sports High Speed Inflator, simply lock the adaptor onto the end of the inflation hose and insert into the valve body. Turn $\frac{1}{4}$ turn to lock in place.

Switch to a SUP hand pump (*#02692, sold separately*) and inflate until gauge on the pump reads 5 – 8 psi. Max inflation pressure is 12 psi. **NOTE: DO NOT INFLATE PRESSURE BEYOND 12 psi. Doing so will cause damage thus voiding warranty.**



Use a RAVE PSI gauge (#02809, sold separately) to ensure correct pressure. NOTE on pressure: The mat will become more rigid with more psi. For example 5 psi is harder to balance on than 8 psi.



To Deflate:

Rapid deflation can be achieved using the “deflate” side of the motor housing on the High Speed Inflator / Deflator. Attach the hose to the deflate side of the motor housing and lock the valve adaptor into the valve.

Move to Water

Carry the product to the water. Use 2 people if needed.

CAUTION: To avoid risk of puncture or damage to the product, ***DO NOT DRAG the product.*** Always carry it to the water. Float the Aqua Power to the desired location for anchoring.

Anchoring

Securing in the Pool

1. Aqua Power comes with 2 sets of Spring Lock Carabiners with swivels. Float the Aqua Power to desired location in the pool.
2. Clip one end of the carabiner to the D-loop on the end of the Aqua Power Mat. Clip other end onto the cable of the lane divider (Repeat this on the opposite side for the most stability.)
3. Optional: An additional D-ring is located on each side of the Aqua Power if users want to connect multiple Aqua Power mats together. Additional Carabiner Kits (#20940) can be purchased separately for this option.

#20940 Carabiner Kit
includes 2 sets of Spring
Lock Swivel Carabiners



Anchoring on the lake

1. In shallow water, link the carabiners onto the plastic D-rings on the Aqua Power. Then tie rope onto the carabiner. You can do this before or after clipping the ring on.
2. Put your anchor on your Aqua Power and make sure it has no pointed parts that can puncture the product. Then tie your rope onto your anchor. If your anchor comes with rope, then just tie your rope on to your carabiners and clip it on D-rings.

3. Float AquaPower mat to the desired location and then drop the anchor and enjoy. Note: You can use two anchors for better stability.

The Aqua Power is now ready for use!

CAUTION! The surface of the Aqua Power can become wet and slippery.



WARNING: DROWNING HAZARD

NEVER ATTEMPT TO SWIM UNDER THE AQUA POWER.
THE AQUA POWER IS A LARGE OBJECT ON THE WATER WITH NO PLACE
TO COME UP FOR AIR IF YOU ARE BENEATH IT.

The Aqua Power is designed to be used as a stand alone product.

Using the Aqua Power

Get fit while having fun!

Yoga is a great way to use the Aqua Power. Why? Because the mat builds up your core by challenging balance and strengthening stability.

Cross training on the Aqua Power will definitely build up balance and enforce aerobic exercises.

Another way to increase the level of exercise is to include **resistance band** activities that can be attached to the Resistance Band strap.



Inflator Options

(Note: These items are not included. Please visit our website at www.ravesports.com to check for availability of the product, or give us a call at 1-800-656-0790 for questions on these products.

SUP Hand Pump (item #02692) is a great cordless option for topping off or inflating any model from the Aqua Power. It is made for stand up paddle boards constructed from the same drop stitch material as used for the Aqua Power.



For a hands free option, the **20psi Auto Inflator & Deflator with battery terminal clips** (item #02693) gets the job done by using the power from the battery on car or watercraft for power. Make sure the hose is connected then set the dial to the recommended pressure. Press the on button and wait for it to finish. It is as easy as that. NOTE: Please check availability of product before ordering.



Cleaning and Storage

- When the inflatable product is not being used, store it in a covered, shaded area. This will help protect it against ultraviolet (UV) rays and extend the life of the product.
- Clean the inflatable completely with a mild soap and fresh water. NEVER USE PETROLEUM BASED PRODUCTS OR SOLVENTS FOR CLEANING. NEVER USE A POWER WASHER SINCE THE HIGH PRESSURE WATER JET WILL DAMAGE THE TUBE BEYOND REPAIR.
- Product should be completely dry and remain dry while stored.
- Roll the product loosely and place in a container, preferably one that rodents can't chew through.
- Secure against unauthorized or unsupervised use.
- Store in a cool, dry location. Do not store product directly on concrete surface. Place mothballs around stored inflatable to keep mice and insects away.

Repairs

For large holes, tears or seam failures, contact RAVE Sports at 1-800-659-0790.

Additional repair patches can be found online at www.ravesports.com.

For minor holes and tears:

- Inflate the product and locate the leak by spraying the tube with mild soapy water.
- Determine the hole size and cut a patch 1-2 inches (3-5 cm) wider than the diameter of the hole. Make sure all corners of the patch are rounded.
- Deflate the product and clean the patch and area around the hole with rubbing alcohol. Let dry completely.
- READ AND UNDERSTAND THE WARNINGS ON THE GLUE CONTAINER.
- Apply glue to the patch and the area around the hole. Let the glue dry until it is tacky to the touch. (About 30 seconds).
- Lay the product on a flat, hard surface and apply the patch. Working from the center to the outer edge, rub out any air bubbles between the patch and the product.
- Let patch dry for 24 hours before attempting to inflate the product.

RAVE
SPORTS®

RAVE
SPORTS®

THIS PAGE INTENTIONALLY LEFT BLANK.

RAVE
SPORTS®

RAVE
SPORTS®



WWW.RAVESPORTS.COM

RAVE SPORTS
A Revel Match, LLC Company
985 Aldrin Drive #301
Eagan MN, 55121
800.659.0790

September 2018 – Version 2.0