




**Mainstreet 35 Inch Air
Hockey Table**

Item 55-0510

MAINSTREET 35 INCH AIR HOCKEY TABLE



Replacement Parts

Order direct at www.gldproducts.com
or call our Customer Service department at
(800) 225-7593
8 am to 4:30 pm Central Standard Time

GLD Products

***Mainstreet 35 Inch Air
Hockey Table***

Item 55-0510

Staple your receipt here.

Important: A copy of your receipt will be needed to activate your warranty (see page 10).





Congratulations and THANK YOU for purchasing the Mainstreet 35 Inch Air Hockey Table. You have chosen a product that should provide years of entertainment. To assist you with customer service and warranty claims, staple your receipt to the inside cover, then keep this manual in a safe place for future reference.













GLD Products

S84 W19093 Enterprise Drive
Muskego, WI 53150 USA
1-800-225-7593
Fax: 1-800-841-6944
Email: gld@gldmfg.com
Web: www.gldproducts.com

This manual may have been updated. For the latest manual visit the GLD Products website.

	<p>Place your package near the location where it will be used. Carefully unpack all components and verify you have all the correct pieces.</p> <p>If you notice missing or defective parts, please call us at: 1-800-225-7593 ext 113</p>
---	--

	<p>Please read and understand all instructions before beginning assembly.</p> <p>This assembly may require 2 adults.</p> <p>This product is not for use by children without adult supervision.</p>
---	---

Part No./ Qty	Illustration/ Order Number	Part No./ Qty	Illustration/ Order Number	Part No./ Qty	Illustration/ Order Number
1 Qty. 1	 Air Hockey Table Order No. 4-158	2 Qty. 2	 Left Leg Order No. 4-159	3 Qty. 2	 Right Leg Order No. 4-160
4 Qty. 4	 6 x 30 mm Leg Bolt Order No. 3-284	5 Qty. 4	 18 x 6.5 mm Washer Order No. 3-268	6 Qty. 8	 3.5 x 12 mm Washer Head Screw Order No. 3-285
7 Qty. 2	 Goal Box Order No. 4-161	8 Qty. 1	 Allen Wrench Order No. 3-190	9 Qty. 2	 Pusher Order No. 4-162
10 Qty. 2	 Hockey Puck Order No. 4-163	11 Qty. 2	 Felt Pad Order No. 4-164	12 Qty. 1	 Adapter Order No. 4-165

IF YOU HAVE A WARRANTY CLAIM, CALL US FIRST

Please see page 10.

GLD Products

Available 8 am to 4:30 pm Central Standard Time

S84 W19093 Enterprise Drive

Muskego, WI 53150 USA

1-800-225-7593

Fax: 1-800-841-6944

Email: gld@gldmfg.com

Web: www.gldproducts.com

For all claims, please have your receipt and item number when you call. The product item number can be found on the front cover.

If you are instructed to return the product for service, you are responsible for shipping the unit at your expense.

PRODUCT REGISTRATION

Important: The product registration form on page 11 and a copy of your receipt must be completed and returned within 10 days of purchase to validate your warranty.

On-line registration is also available.

Go to <http://www.gldproducts.com/index.php/registration> or click on this link. Follow the on-line instructions.

Preparing for Assembly

- Be sure to unpack all of the parts included in this package. Check inside any tubes or sleeves. Save all packing material until the product is fully assembled and functional.
- Compare the parts in your package with the Parts Identifier description on page 4.
- After unpacking large products, some disassembly may be required prior to beginning the assembly.

Tools Required

- Allen wrench (#8) (included with table)
- Phillips screwdriver (not included)
- Level (not included)
- Electric screwdriver may be helpful. **CAUTION:** You must set at LOW TORQUE and use extreme caution because you could overtighten the hardware, strip the screws, or damage the table.

Assembly Tips

Make sure you understand the following before you begin to assemble your game table.

1. READ THIS MANUAL all the way through before beginning assembly.
2. When installing parts that have more than one bolt, start ALL bolts in that part by hand before tightening anything.
3. Some drawings or images in this manual may not look exactly like your product.
4. You may need a second adult to assist with this assembly.

Note: Save all packing materials until the parts have been inspected and the table is assembled.

Unpack the Pieces


- Lay the box on a flat surface (floor). You may want this near your area of assembly.
- Unpack the boxes and part bags. Inspect and count the parts. The Parts Identifier page can be used to record your results.
- If any parts are damaged or missing, contact GLD Customer Service.
- Missing fasteners may be purchased at a hardware store using the descriptions on the Parts Identifier page.

Games

This game table includes the equipment and game pieces for Air Powered Hockey. The rules for this game are not discussed in this manual.

STEP 1 - ATTACH THE LEGS

1. Place the pre-assembled air hockey table (#1) face down on your work area.
2. Position yourself on one of the long sides.
3. Attach a left leg (#2) and a right leg (#3) using a leg bolt (#4) with a washer (#5) for each one.
4. Tighten using the allen wrench (#8).
5. Move to the other side of the table and repeat numbers 3 and 4.
6. From underneath the table, plug in the adapter (#12) cord to the motor.





STEP 2 - TURN THE TABLE OVER


The table is ready to be turned over.

LIFT THE TABLE ASSEMBLY AND TURN IT OVER TO REST ON THE LEGS.

DO NOT ROLL THE TABLE OVER. This will place a sideways force on the legs. The legs should be off the floor until the table assembly is rotated completely. Set the table down.

DO THIS**NOT THIS****STEP 3 - ATTACH THE GOAL BOXES**

1. Position a goal box (#7) on one of the hockey end aprons.
2. Use four washer head screws (#6) to secure the goal box.
3. Repeat numbers 1 and 2 for the other goal box on the opposite side.



STEP 4 - APPLY POWER


The table is powered by the adapter (#12). Plug in the adapter (#12) from under the table into a standard wall plug. The fan will run when the adapter is plugged in.

STEP 5 - LEVEL THE TABLE

1. Place the table in position.
2. Use a carpenter's level to find the low side of the table.
3. Place spacers under the legs as needed to level the table.
4. Level the table side-to-side and end-to-end. When the game is turned on, the puck will float to a low side. Final leveling can be performed if needed.

STEP 6 - ASSEMBLE THE HOCKEY STRIKERS

1. Peel paper from one of the felt pad pieces (#11).
2. Attach the felt pad (#11) to the bottom of the pusher (#9).

**Care and Use of your Table**

- This product is intended for INDOOR use only.
- DO NOT sit, climb, or lean on the table.
- DO NOT drag the table when moving it. This will damage the legs.
- Keep your table covered.
- To clean the hard surfaces spray a cloth with a mild cleaner and wipe.
- Pucks that fly off the table may have chipped edges. Inspect the puck and replace if needed.
- The air holes may become plugged, causing the puck to drag. A small drill bit can be used to re-open the holes. DO NOT use a power drill. Instead, hold the drill bit in your fingers and clear the holes.

90-DAY LIMITED WARRANTY

The Manufacturer warrants to the original retail purchaser that this product is free from defects in material and workmanship under normal use and conditions for a period of ninety (90) days from the date of original purchase. The Manufacturer's liability is limited to the repair or replacement, at its option, of any defective product and shall not include any liability for indirect, incidental or consequential damages of any kind. Should this product become defective due to material or workmanship within the warranty period, contact our Customer Service Department. This warranty is not transferable and does not cover normal wear and tear or damage caused by improper usage, negligence, misuse, abuse, transportation damage, acts of nature, or accident (including failure to follow the instructions in this manual). It does not cover expendable items such as batteries, light bulbs, fuses, accessories, cosmetic parts and other items that wear out due to normal usage, including felt covered areas of the playing surface. This warranty is also void if the product is disassembled and reassembled, damaged, modified from its original state, or used for other than indoor personal residential use (no commercial or rental applications).

This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

IF YOU HAVE A WARRANTY CLAIM, CALL US FIRST (8 - 4:30 CST)

Please have your receipt and item number (found on the front cover) when you call.

GLD Products

S84 W19093 Enterprise Drive

Muskego, WI 53150 USA

1-800-225-7593

Fax: 1-800-841-6944

Email: gld@gldmfg.com

Web: www.gldproducts.com

If you are instructed to return the product for service, you are responsible for shipping the unit at your expense to the above address in packaging that will protect against further damage. All warranty or repair requests require a Return Authorization Number prior to returning the item.

PRODUCT REGISTRATION

Important: The product registration form on page 11 must be completed and returned along with a copy of your receipt within 10 days of purchase to validate your warranty.

On-line registration is also available.

Go to <http://www.gldproducts.com/index.php/registration> or click on this link. Follow the on-line instructions.

REGISTER YOUR PRODUCT

Place postage here

Complete this form, include a copy of your receipt, fold, tape (do not staple) and return within 10 days of purchase. This protects your warranty and will help us develop new products!

Cut here.

GLD Products

Warranty Department
S84 W19093 Enterprise Drive
Muskego, WI 53150 USA

Fold here second.



P R O D U C T S

www.gldproducts.com

GAME TABLES

GAMES AND ACCESSORIES

BILLIARD ACCESSORIES

SOFT-TIP DARTS

FLIGHTS AND SHAFTS

HOME CASINO

BILLIARD CUES

DARTBOARDS

STEEL-TIP DARTS

DART CASES AND ACCESSORIES

Fold here first.

Name	Date of Purchase
Address	Phone-Day
City	Phone-Evening
State Zip	Email
Purchase Price:	Item: 55-0510 Mainstreet 35 Inch Air Hockey Table
Store Name:	

Remember to attach a copy of your receipt.

S84 W19093 Enterprise Drive
Muskego, WI 53150 USA

Email: gld@gldmfg.com

Web Site: www.gldproducts.com

Item 55-0510

Name		Date
Address		Phone-Day
City		Phone-Evening
State	Zip	Email

Shipping will be added. If paid by Check or Money Order, call for quote.

5.1% Waukesha Wisconsin tax will apply (subject to change).

Method of Payment

_____ Check or Money Order

_____ Credit Card

_____ Visa _____ MasterCard _____ Discover _____ American Express

Card # _____

Security Code # _____ Billing Address Zip code _____

Signature _____ Exp. Date _____

Shipping Address

Name _____

Address _____ Phone _____

City _____ State _____ Zip _____



www.gldproducts.com

GAME TABLES

HOME CASINO

GAMES AND ACCESSORIES

BILLIARD CUES

BILLIARD ACCESSORIES

DARTBOARDS

SOFT-TIP DARTS

STEEL-TIP DARTS

FLIGHTS AND SHAFTS


DART CASES AND ACCESSORIES



PROUD MANUFACTURER OF



Yesterday's games for today's families!
by GLD Products



S84 W19093 Enterprise Drive • Muskego, WI 53150 USA
262.679.8730 or 1.800.225.7593 tele
262.679.8738 or 1.800.841.6944 fax
Email: gld@gldmfg.com
www.gldproducts.com