

THE BATTERY

1000mAh

3.7V

Li-Ion

1000mAh

3.7V

Li-Ion

1000mAh

3.7V

Li-Ion

1000mAh

3.7V

Li-Ion

1000mAh

3.7V

Li-Ion

1000mAh

3.7V

Li-Ion

1000mAh

3.7V

Li-Ion

1000mAh

3.7V

Li-Ion

1000mAh

3.7V

Li-Ion

1000mAh

3.7V

Li-Ion

1000mAh

3.7V

Li-Ion

1000mAh

3.7V

Li-Ion

DISASSEMBLY



| Part No. | Part Name | Quantity |
|----------|--------------|----------|
| 1 | Battery Pack | 1 |
| 2 | PCB | 1 |
| 3 | Screw | 4 |
| 4 | Cover | 1 |

DISASSEMBLY INSTRUCTIONS:
1. Remove the cover.
2. Remove the screws.
3. Remove the PCB.
4. Remove the battery pack.

ASSEMBLY INSTRUCTIONS:
1. Insert the battery pack.
2. Insert the PCB.
3. Tighten the screws.
4. Attach the cover.