

O-Cedar®

MaxiClean Eraser Sponge

Quickly and easily removes marks from surfaces such as walls, appliances, baseboards, car interiors and exteriors.

Features

- Chemical free, requires only water
- Thicker sponge allows for added durability

Benefits

- Most effective on hard, smooth surfaces
- Melamie cleaning surfaces on both sides
- Eliminates crayon, ink, permanent marker and scuff marks







O-Cedar®

MaxiClean Eraser Sponge

Product Descriptions

CB961504 - Quickly and easily removes marks from surfaces such as walls, appliances, baseboards, car interiors and exteriors. Chemical-free; requires only water. Most effective on hard, smooth surfaces. Melamine cleaning surfaces on both sides. Eliminates crayon, ink, permanent marker and scuff marks. Each Sponge is 4-1/2" x 2-3/4" x 1-1/2".

Product	Pack size	Dilution	Product code
O-Cedar® MaxiClean Eraser Sponge	6 x 4 pack	Ready-to-Use	CB961504

Safe handling

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use; and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available online at www.diversey.com or by calling 888.352.2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate.