BEST CHOICE PRODUCTS



# INSTRUCTION MANUAL

## Wooden Rolling Kitchen Cart with Towel Bar

Ver. 1

SKY11183

## NOTICE | *Please retain these instructions for future reference.*

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws, or knobs before use.
- Reconfirm that all bolts, screws, or knobs are secure every 90 days.
- Fasten screws loosely during initial assembly. Do not firmly tighten the screws until the item is completely assembled.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Assemble this item on a flat, level, and stable surface for an ideal construction.
- This product is intended for indoor use only.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.
- This product is intended for residential use only.

## TOOLS REQUIRED



ALLEN WRENCH
*(PROVIDED)*



SPANNER
*(PROVIDED)*




66 LBS CAPACITY
*(TABLETOP)*




34 LBS CAPACITY
*(LEAF)*




12 LBS CAPACITY
*(TRAY)*




50 LBS CAPACITY
*(SHELF)*



2 PERSON ASSEMBLY



UP TO 30 MIN. ASSEMBLY

## HARDWARE

**1** M6 x 50mm BOLT



10 PCS

**2** M6 SPRING WASHER



10 PCS

**3** M8 x 30mm DOWEL



14 PCS

**4** M4 x 32mm SCREW



10 PCS

**5** LOCKING CASTER



4 PCS


**6** FOOT PAD



4 PCS


## PARTS

**A** TABLETOP




1 PC

**B** LEG I




1 PC

**C** LEG II



1 PC

**D** SIDE SUPPORT




2 PCS

E MIDDLE SUPPORT




1 PC

F SHELF



1 PC

G BAR SUPPORT




2 PCS

H BAR




1 PC

I SUPPORT ARM



2 PCS


J TRAY



1 PC


## PRODUCT ASSEMBLY

**1** Insert two **part 3 dowels** into one **part D side support.** Repeat for the second side support.





x2

**2** Insert four **part 3 dowels** into one **part F shelf.**





**3** Insert one **part 3 dowel** into one **part G bar support.** Repeat for the second bar support.




x2


**4** Insert the side supports into the **part E middle support.**



## 5

Attach the support assembly and **part F shelf** into their respective receivers on the **part B legs,** secure with four **part 1 bolts** and four **part 2 spring washers,** one bolt and one washer per support.


**NOTE:** Tighten the screw further until semicircular wood area to be flat.




## 6

Attach the **part C legs** to the support with four **part 1 bolts** and four **part 2 spring washers,** one bolt and one washer per support.


**NOTE:** Tighten the screw further until semicircular wood area to be flat.




7 Attach two **part G bar supports** to the **part H bar.**

Insert the bar assembly into the **part B legs,** secure with two **part 1 bolts** and two **part 2 spring washers.**

**NOTE:** Tighten the screw further until semicircular wood area to be flat.




8 Insert four **part 3 dowels** into the top support assembly.




## 9

Place the **part A tabletop** face down on a flat, covered surface to prevent scratches.

Position the four **part I support arms** onto the tabletop as shown.

Turn the cart legs assembly upside down and press the dowels into the tabletop.


Ensure the opening of the cart legs assembly aligns with the support arms.




## 10


Secure **part B & C legs** and two **part D side support** with eight **part 4 screws.**

Secure the **part E middle support** with two **part 4 screws.**




## 11

Attach either four **part 5 locking casters** or four **part 6 foot pads** to the bottom of the cart legs.




## 12

Slide the **part J tray** between the cart legs.





## 13

**Extending the Leaf**

Lift the leaf until it's level with the tabletop. Pull out the **part I support arms** underneath and lock it in place before adding weight.

**Collapsing the Leaf**

Push the **part I support arms** back under the table and gently lower the leaf. Make sure it's fully down and secure before moving or using the table.



# HELP CENTER

Question about your product? We're here to help. Visit us at:

**bestchoiceproducts.com/pages/help**



Chat Support


Product Inquiry


Orders FAQ


Product Assembly


Returns & Refunds

## PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

© Best Choice Products, Inc. All rights reserved. Distributed by Best Choice Products, Inc. Newport Beach, CA 92660

## ⚠WARNING

**Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.**