




























ASSEMBLY INSTRUCTION

PLATFORM QUEEN BED

A Headboard	B Headboard Leg - Left	C Headboard Leg - Right
		
1pc	1pc	1pc
D Footboard	E Footboard Leg - Left	F Footboard Leg - Right
		
1pc	1pc	1pc
G Left Side Rail - Front	H Left Side Rail - Rear	I Right Side Rail - Front
		
1pc	1pc	1pc
J Right Side Rail - Rear	K Side Rail Support Leg	L Slat Roll
		
1pc	2pcs	2sets
M Center Rail	N Slat Support Leg	O JCBB Bolt M8 x 40mm
		
2pcs	4pcs	6pcs

P JCBB Bolt M8 x 20mm	Q Spring Washer M8	R Flat Washer M8
		
8pcs	6pcs	14pcs
S JCBC Bolt M6 x 35mm	T Spring Washer M6	U Flat Washer M6
		
16pcs	16pcs	16pcs
V Allen Key M5	W Allen Key M4	X L-Bracket 22 x 18 x 1mm
		
1pc	1pc	1pc
Y Pan Head Screw M4 x 16mm	Z Pan Head Screw M4 x 30mm	
		
2pcs	24pcs	




These pages list all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

IMPORTANT NOTE :

1. Do not tighten all screws / bolts until all completely assembled.
2. Keep all hardware parts out of reach of children.


1

Attach Headboard Leg - Left & Right (B & C) to Headboard (A) and tighten JCBB Bolt (O), Spring Washer (Q) and Flat Washer (R) with Allen Key (V).

**2**


Attach Footboard Leg - Left & Right (E & F) to Footboard (D) and tighten JCBC Bolt (S), Spring Washer (T) and Flat Washer (U) with Allen Key (W).

Please make sure the arrow on Footboard (D) is facing top.




3

Attach Side Rail Support Leg (K) to Left Side Rail - Front & Rear (G & H) and Right Side Rail - Front & Rear (I & J) and tighten JCBC Bolt (S), Spring Washer (T) and Flat Washer (U) with Allen Key (W).

**4**


Attach Left Side Rail - Front & Rear (G & H) and Right Side Rail - Front & Rear (I & J) to Headboard Leg - Left & Right (B & C) and Footboard Leg - Left & Right (E & F) and tighten JCBB Bolt (P) and Flat Washer (R) with Allen Key (V).

Please make sure the HEADBOARD stickers on Left Side Rail - Front (G) and Right Side Rail - Front (I) are facing Headboard (A).




5

Screw Slat Support Leg (N) to Center Rail (M) and Slat Roll (L).

**6**

Attach Slat Roll (L) to Left Side Rail - Front & Rear (G & H) and Right Side Rail - Front & Rear (I & J) and tighten Pan Head Screw (Z) with Screwdriver (not provided).


Please make sure the arrow on Center Rail (M) is facing Headboard (A).



Please make sure the arrow on Center Rail (M) is facing Footboard (D).

7

Attach L-Bracket (X) to Center Rail (M) and Footboard (D) and tighten Pan Head Screw (Y) with Screwdriver (not provided).



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.