


Exploded drawing



24" Drawer Refrigerator for Outdoor and Indoor Parts List (SRD243SSPR)

No.	Customer No.	Description	Customer Model
			SRD243SSPR
1	607046	Handle	2
4.1	101785	Upper Drawer Door Gasket	1
4.2	101785	Upper Drawer Door Gasket	1
5	602411	Evaporator Cover	1
6	665844	Control Panel Overlay	1
7	601998	Controller Display cover	1
8	648184	Controller Display Panel	1
9	601997	Controller Display Box	1
10	517037	LED Light	2
11	582055	Fan Motor	3
12	540063	Light Switch	1
13	540063	Light Switch	1
14	602237	Kickplate Louver	1
15	648129	Feet	4
16	800335	Evaporator	1
17	602422	Kickplate	1
18	615097	Condenser	1
19	644016	Water Pan	1
20	584032	Compressor	1
21	497296	Main Controller Board	1
22	531184	Power Cord	1
23	517045	Temp Sensor	1
25	601944	slide way	4
26	602184	Fan Cover	1
27.1	880078	Upper Drawer Panel	1
27.2	880079	Lower Drawer Panel	1
28.1	602801	Door Panel	1
28.2	602801	Door Panel	1
29	602884	Cross Holder	1