

## ASSEMBLY INSTRUCTION











1pc





This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

Put the Seat Frame (A) on a smooth flat surface and please flip over the Seat Frame (A), then take out the Seat Cushion (G) from the bottom of it.




2 Hook the Seat Frame (A) onto the Backrest (F) properly.






Please flip over the assembed Seat Frame (A) & Armrest (E) & Backrest (F) on a smooth flat surface. Attach the Leg (D) to them using Screw (I) by Screwdriver (I) as below about

ver (J) as below shown.



Put the Seat Cushion (G) on Seat Frame (A), then put Back Cushion (B) & Arm - Cushion (C) & Pillow (H) on seat Cushion (G) as below shown.




## Cleaning & Care


Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.

## MORE SELECTION STYLE


SSS 11 Seater U Shape Sectional E956CE x 7 + E956CR x 4




LSL 9 Seater L Shape Sectional E956CE x 5 + E956CR x 4



LS 6 Seater L Shape Sectional E956CE x 3 + E956CR x 3




Chaise Sectional with 1 Ottoman E956CE x 2 + E956CR x 2 + E956OT




E956CE + E956CR x 2



SS 7 Seater L Shape Sectional E956CE x 4 + E956CR x 3



LL 5 Seater L Shape Sectional E956CE x 2 + E956CR x 3



U Shape with 2 Ottoman E956CE x 2 + E956CR x 2 + E956OT x 2



Chaise Sectional with 1 Ottoman E956CE x 2 + E956CR x 2 + E956OT

