



## **XOU24ORS\_** 24" OUTDOOR REFRIGERATOR

### LIFESTYLE OUTDOOR REFRIGERATION



**XOU24ORS\_**

- Zero clearance hinges
- Clear glass shelves slide out
- Secure door lock
- Tri-color interior LED lighting


### 24" UNDERCOUNTER OUTDOOR REFRIGERATOR

Store up to 145 (12oz) cans at a frosty 34° to 50° F and still find just what you are looking for. The clear glass shelves slide out while fully loaded making it easier to store and locate contents at a glance. No more fumbling around or emptying the unit to find what you want.

WORLD CLASS SERVICE | COMPREHENSIVE WARRANTIES

**OUR LASTING COMMITMENT TO YOU**

\*Specify **R** for right hand hinge - or - **L** for left hand hinge



## FEATURES

### CAPACITY

Full extension clear glass shelves hold 145 (12oz) cans at 34° to 50° F

### FEATURES

- Zero clearance hinges for flush integration\*
- Secure door lock
- Non- reversible door - specify right or left hinge
- Library quiet 39 dBA operation
- Elegant tri-color interior illumination
- Intuitive digital touch controls
- 6-1/2' Power Cord with low profile 90 flat plug
- Low E Glass blocks harmful UV light
- Alarm Functions
- Energy Saver and Sabbath Mode

Note: zero clearance hinges are visible just above and below the door pane

## SPECIFICATIONS

**ELECTRICAL** 120V 60HZ 4.35 AMP\*

**DIMENSIONS** H 34 1/8"  
W 23 7/8"  
D 23 1/4"

**ROUGH IN** H 34 1/4" min  
W 24"  
D 24"

**REFRIGERANT** R600A




Two Different Style Handles Included

**NEW**



Optional Modern Design Flat Handle


## ROUGH-IN DIMENSIONS



All XO undercounter units arrive pre-wired with low profile plugs for easy installation




Need more space - Cut into an adjoining cabinet to reach an outlet there



When installing with the hinge side next to a wall leave 13 1/2" clearance gap for Cabinet handles

Door must open a minimum of a 110°



The door stop is set at 110°  
But can be reset to 90° or 140°.

If the door cannot open fully  
You cannot extend the shelves.  
Consult the manual for Instructions  
on changing the door stop setting.