


CHOOSE YOUR COLOR, SET YOUR MOOD



Customize the colors on your GX150C2



START HERE

Plug in the UPS, press and hold "POWER" button until UPS starts

SETUP COLOR MODE

Press 3 times to enter "COLOR MODE"

SET COLOR MODE

DISPLAY MUTE Press to scroll ▲▼ through display modes

1	ZEN	
2	CHASING UNICORNS	
3	DISCO	
4	FLOW	
5	BOTTOMS UP	
6	RESPAWN	
7	VEGAS	
8	SLOW ROLL	
9	SHUFFLE	
10	KILLER ROBOT	

SAVE OR CONTINUE

Press "SETUP" to save your settings and exit

CUSTOM COLOR MODE

11	SOLID	
12	PULSE	

1x SETUP Press "SETUP" to save your settings. Now set your color

CUSTOM COLORS

DOWN DISPLAY MUTE UP Press to select your color

1	RED
2	ORANGE
3	YELLOW
4	GREEN
5	TEAL
6	BLUE
7	HOT PINK

SAVE & EXIT

1x SETUP Press "SETUP" to save your settings and exit

LIGHTS DIM, OFF, ON

Press "MUTE" + "SETUP" to change brightness level

DISPLAY MUTE SETUP PRESS BOTH

DIM #1 → OFF #2 → ON #3