


ASSEMBLY INSTRUCTION









The first & second pages list all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

Assemble Leveler (AJ) to bottom of Right Frame (B) as below shown.


AJ 🕹 2pcs




2 Assemble Leveler (AJ) to bottom of Left Frame (A) as below shown.




Assemble Stretcher (L) & Back Panel - Bottom (E) to Left Frame (A) and Right Frame (B), using Bolt (Y) and Bolt (AA), Flat Washer (AC) to tighten by Allen Key (AG) as below shown.




Assemble Back Panel - Top (C) & Front Panel - Bottom (E) to Left Frame (A) and Right Frame (B), using Bolt (Y), Flat Washer (AC) and the iron sheet of Anti-Tipping Kit (AH) to tighten by Allen Key (AG) as below shown.







First, assemble part one of Slide Rail (R) to Left Panel (F) and Right Panel (G), using Screw (U) by Screwdriver (AI). Second, assemble Bolt (AD) & Wood Dowel (AF) to Left Panel (F) & Right Panel (G) to fasten by Screwdriver (AI).




Assemble Bottom Panel (K) to Left Panel (F) and Right Panel (G), using Nut (AE) to lock with Bolt (AD) & Wood Dowel (AF) to tighten by Screwdriver (AI).




Put Back Panel (H) into Left Panel (F), Right Panel (G) and Bottom Panel (K) as below shown.




First, assemble Support (J) to Top Panel (I), using Screw (V) by Screwdriver (AI). Second, assemble Bolt (AD) & Wood Dowel (AF) to Top Panel (I) to fasten by Screwdriver (AI).




Assemble Top Panel (I) to Left Panel (F) and Right Panel (G), using Nut (AE) to lock with Bolt (AD) & Wood Dowel (AF) by Screwdriver (AI).




Assemble Left Panel (F) & Right Panel (G) to Left Frame (A) & Right Frame (B), using Bolt (Z) & Flat Washer (AC) to tighten by Allen Key (AG).




Assemble Front Panel - Bottom (D) to Bottom Panel (K) with L-Shape Sheet (T), using Bolt (Y), Bolt (Z) & Flat Washer (AC) by Allen Key (AG).




Assemble part 2 of Slide Rail (R) to Drawer Panel - LSF (N) and Drawer Panel - RSF (O), using Screw (U) to tighten by Screwdriver (AI).




Assemble Drawer Back Panel (P) to Drawer Side Panel - LSF (N) and Drawer Side Panel - RSF (O), using Screw (W) by Screwdriver (AI).






Assemble Drawer Front Panel (M) to Drawer Side Panel - LSF (N) and Drawer Side Panel - RSF (O), using Screw (W) by Screwdriver (AI).




17

Assemble Handle (S) to Drawer Front Panel (M), using Bolt (X) & Flat Washer (AB) to fasten by Screwdriver (AI).




Attach the pre-assembled drawer by using Slide Rail (R) to the pre-assembled Desk. Move slide ball spacers to front. Hold drawer horizontally, and slide runners into ball spacers.



19

Remark: there is a tip restraint kit provided on the back of this product. Please read the instruction thoroughly and in stall immediately when placed in home. To prevent tip over, the product must be attached to wall.



Adjust any parts out of alignment and tighten all bolts and screws from steps 1 through 19.

Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.