

ATTENTION

Before installing the clock movement batteries, you should remove the plastic bag used to protect the hour and minute hand during shipment.

The end of the bag can be found exiting behind the back of the clock and secured with tape. Carefully peel back the tape strip and gently pull the end of the bag straight away from the center of the clock.