







































ASSEMBLY INSTRUCTION

TV STAND

A Top Panel	B Bottom Panel	C Side Panel	D Middle Panel - Left
			
1pc	1pc	2pcs	1pc
E Middle Panel - Right	F Front Post - Left	G Front Post - Right	H Upper Rail
			
1pc	1pc	1pc	1pc
I Bottom Rail	J Bottom Side Rail	K Middle Shelf Panel	L Middle Shelf Rail
			
2pcs	2pcs	2pcs	2pcs
M Side Shelf Panel	N Door (L / R)	O Middle Back Panel	P Side Back Panel
			
4pcs	2pcs	1pc	2pcs
Q Wood Dowel Ø10x30mm	R Bolt Ø5x25mm	S Nut Ø15x12mm	T Bolt Ø6x50mm
			
31pcs	42pcs	42pcs	4pcs
U Allen Key M4	V Shelf Support Ø5x16mm	W Iron Sheet 46x13x1mm	X Screw Ø3.5x12mm
			
1pc	24pcs	2pcs	4pcs

Y Screw Ø3x15mm 	Z Hanging Trough L=1200mm 	AA Hook 118x20x18mm 	AB Fixed Piece 62x26x2mm 
44pcs	1pc	4pcs	2pcs
AC Baffle 67x20x20mm 	AD Bolt Ø1/4"x28mm 	AE Bolt 1/4"x10mm 	AF Flat Washer Ø16mm 
2pcs	4pcs	8pcs	12pcs
AG Screw Ø4x32mm 	AH Screw Ø4x12mm 	AI Glue 	AJ Anti-Tipping Kit 
4pcs	6pcs	1pc	2sets
AK Screwdriver (Not Provided) 			
1pc			




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


ASSEMBLY

Do not fully tighten all bolts until assembly is complete. This will help all parts to assemble properly.


- 1** Attach Bolt (R) to Top Panel (A), Bottom Panel (B) using by Screwdriver (AK) as below shown.




- 2** Attach Bolt (R) to Front Post - Left (F), Front Post - Right (G), Bottom Rail (I), Front Middle Rail (L) by Screwdriver (AK) as below shown.




- 3** Attach two pieces of Bottom Rail (I) to Bottom Side Rail (J), Bottom Panel (B) using Wood Dowel (Q) by Glue (AI), then attach Nut (S) to Bolt (R) in Bottom Panel (B) by Screwdriver (AK) as below shown.




- 4** Attach Middle Shelf Rail (L) to Middle Shelf Panel (K), and Front Post - Left (F) & Front Post Right (G) to Side Panel (C), using Wood Dowel (Q) by Glue (AI), then attach Nut (S) to Bolt (R) in Side Panel by Screwdriver (AK).




- 5** Attach Middle Panel - Right (E) & Middle Panel - Left (D) to Bottom Panel (B) using Wood Dowel (Q) by Glue (AI), and using Bolt (T) to tighten by Allen Key (U).




- 6** Attach the assembled Side Panel (C) to Bottom Panel (B) using Wood Dowel (Q) by Glue (AI), and attach Nut (S) to Bolt (R) in Bottom Panel (B) tighten by Screwdriver (AK).




- 7** Attach Upper Rail (H) to Hanging Trough (Z) using Bolt (AD), Flat Washer (AF) to tighten by Screwdriver (AK).




- 8** Attach the assembled Upper Rail (H) to Middle Panel - Left (D) & Middle Panel - Right (E) using Wood Dowel (Q) by Glue (AI).




- 9** Attach Upper Rail (H) to Front Post - Left (F) & Front Post - Right (G) using Iron Sheet (W), Screw (X) by Screwdriver (AK).




- 10** Attach Top Panel (A) to the Side Panel (C), Middle Panel - Left (D) & Middle Panel - Right (E) using Wood Dowel (Q) by Glue (AI), then attach Nut (S) to Bolt (R) in all panels by Screwdriver (AK) as below shown.




- 11** Attach Side Back Panel (P) & Middle Back Panel (O) to Side Panel (C), Top Panel (A), Middle Panel - Left (D) & Middle Panel - Right (E) using Screw (Y) to tighten by Screwdriver (AK).




- 12** Insert Shelf Support (V) to the assembled Side Panel (C), Middle Panel - Left (D) & Middle Panel - Right (E), then attach Middle Shelf Panel (K) & Side Shelf Panel (M) on the Shelf Support (V) as below shown.
Remark: There are 3 options for you to adjust the height of the shelf support.




13 Attach Baffle (AC) & Fixed Piece (AB) to Door (N), using Screw (AG), Screw (AH) by Screwdriver (AK) as below shown.




14 Attach Hook (AA) to Door (N), using Bolt (AE), Flat Washer (AF) by Screwdriver (AK) as below shown.



- 15** The back of the Door (N) faces the cabinet body, and then hook the Door (N) on the Hanging Trough (Z), and at the same time put the Fixed Piece (AB) at the Bottom of the Door (N), into the slot of Bottom Panel (B).



- 16** Remark: there is a tip restraint kit provided on the back of this product. Please read the instruction thoroughly and install immediately when placed in home. To prevent tip over, the product must be attached to wall.



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.