




BEST CHOICE
PRODUCTS



INSTRUCTION MANUAL

5-Piece Modern Dining Set with
Steel Frame and Storage Rack




! NOTICE | Please retain these instructions for future reference.

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws, or knobs before use.
- Reconfirm that all bolts, screws, or knobs are secure every 90 days.
- Fasten screws loosely during initial assembly. Do not firmly tighten the screws until the item is completely assembled.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Assemble this item on a flat, level, and stable surface for an ideal construction.
- This product is intended for indoor use only.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer’s instructions as this could void the product warranty.
- This product is intended for residential use only.

TOOLS REQUIRED




HARDWARE



PARTS

A


TABLETOP



1 PC

B

TABLE LEGS



2 PCS

C

SHELF



1 PC

D


TABLE SUPPORT BAR



2 PCS

E


CHAIR LEFT SIDE



4 PCS

F


CHAIR RIGHT SIDE



4 PCS

G


BACKREST



4 PCS

H


UPPER CHAIR SUPPORT



8 PCS

I


SEAT



4 PCS

J

LOWER CHAIR SUPPORT



8 PCS


PRODUCT ASSEMBLY - TABLE

1

Locate two **part B table legs**, and attach two **part D table support bars** with eight **part 1 screws**, four screw per leg set.




Fasten screws loosely during assembly. Do not firmly tighten screws until item is fully assembled.



2

Place the **part A tabletop** face down onto a soft, level surface.

Flip the table frame assembly and place it onto the tabletop, then attach the tabletop to the **part B legs** and **part D support bars** with eight **part 1 screws**.




3

Attach the **part C shelf** to the **part B table legs** with four **part 1 screws**.



Fasten screws loosely during assembly. Do not firmly tighten screws until item is fully assembled.



PRODUCT ASSEMBLY - CHAIRS

1

Place the **part E chair left side** onto its side.

Attach the **part G backrest** with two **part 3** screws.


Attach the **part F chair right side** to the backrest with two **part 3** screws.

Attach two **part H upper chair supports** to the **part E & F chair sides** with four **part 2** screws.

Attach two **part J lower chair supports** to the **part E & F chair sides** with four **part 2** screws.



Fasten screws loosely during assembly. Do not firmly tighten screws until item is fully assembled.




x4

- 7** | Flip the chair assembly, then attach one **part I seat** with four **part 2 screws**. Flip the assembled chair upright. Repeat **steps 1-2** to assemble the remaining chairs.



Fasten screws loosely during assembly. Do not firmly tighten screws until item is fully assembled.



x4



HELP CENTER

Question about your product? We're here to help. Visit us at:

bestchoiceproducts.com/pages/help



Chat Support



Product Inquiry



Orders FAQ



Product Assembly



Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

© Best Choice Products, Inc. All rights reserved. Distributed by Best Choice Products, Inc. Newport Beach, CA 92660

WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.