

AEROFLY TRANSPORT CHAIR



- | | |
|---|---|
| 1. Armpad Right- AEROFLY-01 | Clothing Guard Right- AEROFLY-22 |
| Armpad Left- AEROFLY-02 | 17. Hand Brake Assy- AEROFLY-23T |
| 2. Back Cushion Blue 18"- AEROFLY-04-18 | 18. Seat Upholstery 18"- AEROFLY-24-18 |
| Back Cushion Red 18"- AEROFLY-05-18 | 19. Seat cushion Blue 18"- AEROFLY-26-18 |
| 3. Back Upholstery 18"- AEROFLY-07-18 | Seat cushion Red 18"- AEROFLY-27-18 |
| 4. Brake Cable- AEROFLY-08T | 20. Fork Assembly- AEROFLY-29 |
| 5. Brake Left- AEROFLY-09T | 21. Fork Stem Bearing- AEROFLY-30 |
| Brake Right- AEROFLY-10T | 22. Footrest Attachment Block- AEROFLY-31 |
| 6. Hand Grip- AEROFLY-43 | 23. Footplate Right- AEROFLY-32 |
| 7. Handlebar Assy Left Gray- AEROFLY-12 | Footplate Left- AEROFLY-33 |
| Handlebar Assy Left Black- AEROFLY-12BLK | 24. Cross Frame 18" Gray- AEROFLY-34T |
| Handlebar Assy Right Gray- AEROFLY-13 | Cross Frame 18" Black- AEROFLY-34BLKT |
| Handlebar Assy Right Black- AEROFLY-13BLK | 25. Cross Frame Guide Set- AEROFLY-35 |
| 8. Handlebar Release- AEROFLY-14 | 26. Cross Frame End Cap Set- AEROFLY-36T |
| 9. Rear Wheel- AEROFLY-15T | 27. Side Frame Left 18" Black- AEROFLY-37BLKT |
| 10. Rear Wheel Bearing- STDS1060 | Side Frame Left 18" Gray- AEROFLY-37T |
| 11. Quick Release axle- AEROFLY-17T | Side Frame Rt 18" Black- AEROFLY-38BLKT |
| 12. Q/R axle sleeve- AEROFLY-18T | Side Frame Right 18" Gray- AEROFLY-38T |
| 13. Caster- AEROFLY-19 | 28. Frame End Caps (pr)- AEROFLY-39 |
| 14. Caster Bearing- STDS1011 | 29. Footrest (pr)- AEROFLY-42 |
| 15. Caster Axle- AEROFLY-20 | n/s Anti-Tippers (pr)- AEROFLY-40 |
| 16. Clothing Guard Left- AEROFLY-21 | n/s Cup Holder Bracket- AEROFLY-41 |

1/29/2026