




BEST CHOICE  
PRODUCTS



# INSTRUCTION MANUAL

---

L-Shape Modular Desk

## ! NOTICE

Please retain these instructions for future reference.

- Please do not exceed the weight limitations of this item, Firmly secure all bolts, screws, and knobs before use.
- Do not stand on or use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- If any parts are missing, broken, damaged, or worn, stop using this item until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.
- This product features two assembly options for the shelving section. Follow instructions carefully for best results.
- This product is intended for residential use only.

## TOOLS REQUIRED



ALLEN WRENCH  
(PROVIDED)



WRENCH  
(PROVIDED)



110LBS  
TABLE  
CAPACITY



17LBS  
SHELF  
CAPACITY



2 PERSON  
ASSEMBLY



UP TO 45 MIN.  
ASSEMBLY

## HARDWARE

### A M6 X 40MM SCREWS



34 PCS

### B M6 X 30MM BOLTS



8 PCS

### C Ø4 x 25MM SCREWS



20 PCS

### D WASHER



4 PCS

### E CROSSBAR NUT



2 PCS

### F M6 X 12MM SCREWS



20 PCS


### G Ø4 x 30MM SCREWS



8 PCS

## PARTS

### 1 SHELF FRAME




2 PCS

### 2 SHELF SUPPORT



10 PCS

### 3 TABLE LEG JOINER




1 PC

## PARTS

4


TABLE TOP SUPPORT I



1 PC

5


TABLE BASE SUPPORT BAR I



1 PC

6


TABLE SIDE PANEL



1 PC

7


TABLE BASE SUPPORT BAR II



2 PCS

8


TABLE TOP SUPPORT II



1 PC

9


TABLE END FRAME



2 PCS

10


TABLETOP LEAF SUPPORT I



1 PC

11


TABLETOP LEAF SUPPORT II



1 PC

12

SHELF



5 PCS

13

TABLETOP I



1 PC

14

TABLETOP II



1 PC

15

CROSS BAR



4 PCS




Fasten screws loosely during initial assembly. Do not tighten screws until item is completely assembled.

## PRODUCT ASSEMBLY


1

Attach the **part 3 table leg joiner** to the **part 4 table top support (L)** with two **part F screws**.  
Attach the **part 5 table base support bar (L)** to the **part 3 joiner** with two **part F screws**.



2


Attach the **part 6 table side frame** to the **part 4 & 5 framing bars** with two **part A screws**.



## PRODUCT ASSEMBLY

3


Attach one **part 7 table base support bar (II)** to the **part 3 joiner** with two **part F screws**.  
Attach one **part 8 table top support (II)** to the table side frame with one **part A screw**.



4

Attach one **part 9 table end frame** to the **part 4, 7, & 8 support bars** with three **part A screws**.

**NOTE:** Identify the outer face of the **part 9 panel** by locating to holes on the back support bar. Make sure the outer face faces outward of the assembly.




## PRODUCT ASSEMBLY

5


Attach one **part 7 table base support (II)**, one **part 10 table top leaf support (I)**, and one **part 11 table top leaf support (II)** to a **part 9 end frame** with three **part A screws**.

**NOTE:** Identify the outer face of the **part 9 panel** by locating to holes on the back support bar. Make sure the outer face faces outward of the assembly.



6


Connect the two assemblies with four **part F screws** and one **part A screw**.



## PRODUCT ASSEMBLY


7

Attach the **part 13 & 14 table tops** to the frame assembly with eight **part B table bolts** and eight **part G table screws**.



8


Attach ten **part 2 shelf supports** to one **part 1 shelf frame** with ten **part A screws**.



## PRODUCT ASSEMBLY

9


Attach another **part 1 shelf frame** to the shelf supports with ten **part A screws**.



10

Attach one **part 12 shelf** to two **part 2 shelf supports** with four **part C screws**. Repeat four times to attach the remaining shelves.


**NOTE:** Insert screws from the bottom of the shelf through holes in the supports.



## PRODUCT ASSEMBLY

11


Attach the shelf assembly to one of the **part 9 end frames** with four **part A screws** and four **part D washers**.



## PRODUCT ASSEMBLY

11


(Alternative) Attach the shelf assembly to one of the **part 9 end frames** with four **part A screws** and **four part D washers**.



## PRODUCT ASSEMBLY

12

Attach two sets of **part 15 crossbars** with eight **part F screws**, then secure the two sets with one **part F screw** and one **part E nut**.





# HELP CENTER



Question about your product? We're here to help. Visit us at:

[help.bestchoiceproducts.com](http://help.bestchoiceproducts.com)



Product Assembly



Returns & Refunds

## PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

## WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.