

















ASSEMBLY INSTRUCTION

LEAVES DINING TABLE


| | | | |
|---|---|---|--|
| A Leaf A  1 pc | B Leaf B  1 pc | C Table Top  1 pc | D Left Leg  2 pcs |
| E Right Leg  2 pcs | F Stretcher  2 pcs | G Trim  4 pcs | H Flat Washer 1/4"*3/4"  4 pcs |
| I Lock Washer 1/4"*1/2"  4 pcs | J Bolt 1/4"*3"  4 pcs | K Flat Washer 5/16"*3/4"  8 pcs | L Lock Washer 5/16"*1/2"  8 pcs |
| M Bolt 5/16"*2-1/4"  8 pcs | N Allen Wrench 1/6 "  1 pc | O Bolt Tensioner 31-3/4"*1-3/8"*7/8"  2 pcs | |



This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


1

Place the table top(C) upside down smooth carpet surface. Tighten the left legs(D) and the right legs(E) on the corner blocks by bolts(M), lock washers(L) and flat washers(K) with allen wrench(N). Tighten the stretchers(F) on the legs by bolts(J), lock washers(I) and flat washers(H) with allen wrench(N). Insert the bolt tensioners(O) into the table top and the stretchers. Insert the trims(G) into the legs.




2

Turn the table on the floor.




3

Open the table top(C), put the leaf A & B on the slides.



4

Make sure the table is level, and then securely tighten all bolts at this stage. Assemble is completed.



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.