


JAXON COMPACT OPEN TURNTABLE STAND ASSEMBLY INSTRUCTIONS

Thank you for purchasing the Jaxon Compact Open Turntable Stand. Please read the instruction carefully to ensure safe operation of the product.




Size: L45xW40xH80cm

PLEASE READ this sheet prior to assembly to familiarize yourself with the various stages of construction.

Carefully open the pack supplied and check the contents against the parts and fittings check list. Do not destroy any of the packaging until you are certain that you have all the necessary parts for the assembly.

CAUTION : There are small components used in the construction of this unit. These loose items should be kept away from young children whilst assembling your unit to avoid the danger of choking hazards.

Tools Required



IMPORTANT - READ CAREFULLY - RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

INFORMATION

Due to the size of this product we recommend that it is assembled in the room intended for use.

When you are ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to prevent it from scratching.

Check the pack and make sure you have all the parts listed.

Ensure that this product is fully assembled as illustrated before use.

Check all screws or bolts are tightened and inspect regularly

This product should only be used on firm, level ground.

Keep small parts out of reach of children.

Make sure the legs remain in contact with the ground.

Tools not included.

WARNINGS

DO NOT use power tools to construct this product.

DO NOT over tighten screws or bolts.

DO NOT use this product if parts are missing, damaged or worn.

DO NOT stand on the product.

DO NOT place very hot or very cold items on the surface unless adequately thick tablemats are used to prevent such items damaging your dresser top

We recommend the use of the wall safety bracket provided for safety reasons.

N.B. wall fixings suitable for a solid wall are included although the wall plug provided may not be suitable for other types of walls such as hollow walls.

Fixings suitable for your wall types must be obtained separately.

If in doubt please consult a qualified trade person.


Always ensure the area to be drilled is free from hidden electrical wires, water and gas pipes.

CARE INFORMATION

Never use scourers, abrasives or chemical cleaners.








To clean wipe with a sponge and warm soapy water. Do not use solvent based cleaners or detergents as they can bleach or damage the product.

JAXON COMPACT OPEN TURNTABLE STAND ASSEMBLY INSTRUCTIONS




JAXON COMPACT OPEN TURNTABLE STAND ASSEMBLY INSTRUCTIONS

Parts

			
Qty: 1PC Top panel	Qty: 1PC Bottom panel	Qty: 1PC Left hand side panel	Qty: 1PC Right hand side panel
			
Qty: 1PC Shelf panel	Qty: 1PC Back panel upper	Qty: 1PC Back panel lower	Qty: 4PCS Leg

Fittings(to scale)

Ref	Dimensions	Qty
A	Cam bolt (5x40mm)	8
B	Cam (10x15mm)	8
C	Wood dowel (8x30mm)	12
D	Screw (4x12 mm)	21
E	Screw (4x30 mm)	1
F	Screw (6x10 mm)	6
G	Screw (5x35 mm)	4
H	Screw (3x16 mm)	8




(Not to scale)

I	Leg Bracket	4	
J	WallBracket	1	
K	Wall Plug	1	
L	Support Bars	3	
M	Back Panel Support	8	
N	Allen key M4	1	
O	Allen key M3	1	

JAXON COMPACT OPEN TURNTABLE STAND ASSEMBLY INSTRUCTIONS



Layout Parts on Soft Surface

Lay out all parts on a soft surface i.e. Rug, Carpet or Packaging Carton





CAUTION: There are many small components used in the construction of this product. Please keep these components away from young children whilst assembling this product. If you keep the fittings in a bowl during assembly you will be less likely to lose them!



JAXON COMPACT OPEN TURNTABLE STAND ASSEMBLY INSTRUCTIONS

STEP 1	Parts Required
	① X 1 ③ X 1 ④ X 1 A X 8 D X 1 J X 1 N X 1
STEP 2	Parts Required
	③ X 1 ④ X 1 ⑤ X 1 B X 4 C X 4



JAXON COMPACT OPEN TURNTABLE STAND ASSEMBLY INSTRUCTIONS

STEP 3	Parts Required
	⑥ x 1 ⑦ x 1
STEP 4	Parts Required
	② x 1 D X 20 I X 4 N X 1


JAXON COMPACT OPEN TURNTABLE STAND ASSEMBLY INSTRUCTIONS

STEP 5	Parts Required
	② x 1 C X 4 G X 4 O X 1
STEP 6	Parts Required
	⑧ x 4



JAXON COMPACT OPEN TURNTABLE STAND ASSEMBLY INSTRUCTIONS

STEP 7	Parts Required
	FX 6 LX 3 NX 1
STEP 8	Parts Required
	① X 1 BX 4 CX 4


JAXON COMPACT OPEN TURNTABLE STAND ASSEMBLY INSTRUCTIONS

STEP 9	Parts Required
	H X 8 M X 8 N X 1

JAXON COMPACT OPEN TURNTABLE STAND ASSEMBLY INSTRUCTIONS

STEP 10	Parts Required
Position the turntable stand against the wall that it will be fastened to and using a pencil, mark the position of the screw holes onto the wall. Drill where the holes have been marked and insert the wall plugs ensuring the edge is flush with the surface of the wall.  	K X 1


JAXON COMPACT OPEN TURNTABLE STAND ASSEMBLY INSTRUCTIONS

STEP 11	Parts Required
 NOTE: The wall fixing plug Supplied with this product is suitable for solid and brick walls. For hollow and stud type walls fixing devices suitable for those type of walls must be obtained separately. Please make sure that the area to be drilled is free from hidden wires, water and gas pipes. Please ensure the fixing is safe and secure before use.	E X 1 N X 1


JAXON COMPACT OPEN TURNTABLE STAND ASSEMBLY INSTRUCTIONS

Complete Assembly

Your JAXON COMPACT OPEN TURNTABLE STAND is now completely assembled. Periodically check that the components are in the correct position and free from damage. Also make sure the connectors are tight and secure.



Keep instructions for future reference.



Supplied by: GFW THE FURNITURE WAREHOUSE
Waterside Distribution Centre
Waterside Business Park
Johnson Road Lancashire
BB3 3RT
www.gfwlimited.co.uk