



zuo®


ITEM NAME/NOM D'ITEM: GUS DRESSER
ITEM #/NO.ITEM: 110632


PARTS LIST/LISTE DES PIÈCES


(1)	(2)	(3)
 x1	 x2	A.  x6 JCBB M8 X 35mm
		B.  x1 ALLEN KEY M5
		C.  x6 SPRING WASHER 5/16
		D.  x4 NAIL GLIDE

ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE


I









Please switch the drawer handles from the inside to the outside.






Cabinet legs are stored in the drawer

II



Useful tips : assemble the furniture on the packing carton to prevent scratches.

III



For missing parts or damaged parts, please call /
Pour pièce manquante ou endommagée, veuillez appeler:

USA, Canada and Mexico:(866)798-6663

AI-V2-J012-250723