


ASSEMBLY INSTRUCTION


CORNER

A Seat Frame




1pc

B Back Cushion



1pc

C Arm Cushion




1pc

D Leg




4pcs

E Armrest




1pc

F Backrest



1pc

G Seat Cushion



1pc

H Pillow




1pc

I Screw
Φ5/32"x2"




4pcs

J Screwdriver
(Not provided)




1pc




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


- 1 Put the Seat Frame (A) on a smooth flat surface and please flip over the Seat Frame (A), then take out the Seat Cushion (G) from the bottom of it.




- 2 Hook the Seat Frame (A) onto the Backrest (F) properly.




- 3** Hook the Seat Frame (A) & Backrest (F) onto the Armrest (E) properly.



- 4** Please flip over the assembled Seat Frame (A) & Armrest (E) & Backrest (F) on a smooth flat surface. Attach the Leg (D) to them using Screw (I) by Screwdriver (J) as below shown.



- 5** Put the Seat Cushion (G) on Seat Frame (A), then put Back Cushion (B) & Arm - Cushion (C) & Pillow (H) on seat Cushion (G) as below shown.




Cleaning & Care


Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.

MORE SELECTION STYLE


SSS 11 Seater U Shape Sectional
E956CE x 7 + E956CR x 4




SS 7 Seater L Shape Sectional
E956CE x 4 + E956CR x 3




LSL 9 Seater L Shape Sectional
E956CE x 5 + E956CR x 4




LL 5 Seater L Shape Sectional
E956CE x 2 + E956CR x 3




LS 6 Seater L Shape Sectional
E956CE x 3 + E956CR x 3




U Shape with 2 Ottoman
E956CE x 2 + E956CR x 2 + E956OT x 2




Chaise Sectional with 1 Ottoman
E956CE x 2 + E956CR x 2 + E956OT




Chaise Sectional with 1 Ottoman
E956CE x 2 + E956CR x 2 + E956OT



Sofa
E956CE + E956CR x 2



LoveSeat
E956CR x 2




ASSEMBLY INSTRUCTION

ARMLESS CHAIR

A


Seat Frame



1pc

B


Back Cushion



1pc

C

Seat Cushion



1pc

D


Leg



1pc

E

Backrest




1pc

FScrew
 $\Phi 5/32"$ x2"

1pc


GScrewdriver
(Not provided)

1pc




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


-
- 1** Put the Seat Frame (A) on a smooth flat surface and please flip over the Seat Frame (A), then take out the Seat Cushion (C) from the bottom of it.




-
- 2** Hook the Seat Frame (A) onto the Backrest (E) properly.



- 3** Please flip over the assembled Seat Frame (A) & Backrest (E) on a smooth flat surface. Attach the Leg (D) to them using Screw (F) by Screwdriver (G) as below shown.



- 4** Put the Seat Cushion (C) on Seat Frame (A), then put Back Cushion (B) on seat Cushion (C) as below shown.




Cleaning & Care


Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.

MORE SELECTION STYLE


SSS 11 Seater U Shape Sectional
E956CE x 7 + E956CR x 4




SS 7 Seater L Shape Sectional
E956CE x 4 + E956CR x 3




LSL 9 Seater L Shape Sectional
E956CE x 5 + E956CR x 4




LL 5 Seater L Shape Sectional
E956CE x 2 + E956CR x 3




LS 6 Seater L Shape Sectional
E956CE x 3 + E956CR x 3




U Shape with 2 Ottoman
E956CE x 2 + E956CR x 2 + E956OT x 2




Chaise Sectional with 1 Ottoman
E956CE x 2 + E956CR x 2 + E956OT



Chaise Sectional with 1 Ottoman
E956CE x 2 + E956CR x 2 + E956OT



Sofa
E956CE + E956CR x 2



LoveSeat
E956CR x 2

