

# Internal PC Speaker

Stereo Speaker Set for  
5.25" PC Drive Bay

SPEAKERINT

## Features

- 10W built-in stereo music amplifier
- Fits exactly into 5.25" drive bays
- Speaker angle is adjustable 15 degrees left or right
- Front panel volume control and headphone jack
- Power indicator LED
- Includes PC backplate with wire to connect to sound card's external output jack
- Uses internal PC power supply (cable included)



## Installation

1. Open the case of your computer and remove one of the extra 5.25" drive bay covers.
2. Insert the SPEAKERINT into the empty drive bay. Align the holes of the speaker unit to the ones of your computer case. Insert the screws. Make sure the speaker unit is mounted properly with the cables inside while the speaker is facing outward.
3. Connect the power supply cable to the speaker unit's power cable socket.
4. Secure the speaker's mounting bracket on one of the empty slots in your computer. (Be sure that the cable connector has been placed through the whole on the bracket before securing the speaker).
5. Plug the speaker connector into the speaker jack of your audio card.
6. Place the computer case back on and ensure that it is properly secured.
7. Adjust the volume of the audio card to the mid-level position.
8. Restart the computer and run the audio system. Test the speaker volume by adjusting the controls on the speaker's front panel.
9. Adjust the angle position of the speaker.



HOME CABLES NETWORKING PARTS STRUCTURED WIRING KVM/VIDEO SWITCHES SERVER RACKS INTERNET SOFTWARE  
www.startech.com 1-800-265-1844 ISO 9001

StarTech.com 